



Contents

Contents.....	1
1. Administration	4
1.1 Scope.....	4
1.2 Purpose	4
1.3 Installer Certification, Indemnification, release and waiver	4
1.4 Retroactivity	7
1.5 Equivalency	7
1.6 Units	7
2. Definitions	7
2.1 Definitions	7
3. General Requirements	8
3.1 Qualifications	8
4 Automist System	8
4.1 Introduction	8
4.2 System Diagram	11
4.3 Technical limitations	12
4.4 Spray Head	14
4.5 Pump	16
Automist Pump Specification.....	17
AP09 230V 50Hz.....	17
AP12 240V 60Hz.....	17
4.6 Controller	18
Automist Controller Specification.....	18
Controller terminals	19
4.7 Smoke Sensor.....	20
EVCA-PY-PL.....	20
4.8 Pipes and Fittings	21
4.9 Data and Sensor Cables.....	22
Data cable specification	22
Sensor Cable Specifications	22
Wire Terminations	22
4.10 Battery for Controller.....	22
Battery specification	22
4.11 System Strainer	23

5 Spray Head Position and Location	23
5.1 Design Criteria	23
5.2 Position of Spray Heads	26
5.3 Working Plan Drawing	32
5.4 Location of Spray Heads	33
6 Smoke Sensor Position and Location	33
6.1 Design Criteria	33
6.2 Position of Smoke Sensors	33
6.3 Smoke Sensor Working Plan	33
6.4 Smoke Sensor Location	33
7 Water Supply	34
7.1 Flow, Pressure and Temperature Requirements	34
7.2 Water Quality	34
8 Electrical Power Supply	34
8.1 230/240V 50/60Hz primary power	34
8.2 12V Standby Battery	34
9. Installation	35
9.1 Water Supply (stock cock and pressure gauge)	35
9.2 High-Pressure Pipes and Fittings (indoor install)	36
9.3 Data Cables	37
9.4 Smoke Sensor Wiring	37
9.5 Spray Head Installation	38
9.6 Controller Installation	40
9.6.1 Connecting the Backup Battery	42
9.7 Pump Installation	42
9.8 Zone Configuration	46
9.9 Powering up the system	48
9.9.1 Setting the time and date	48
9.9.2 Commissioning	49
9.9.2.1 Commissioning Stage 1 - Addressing	50
9.9.2.2 Commissioning Stage 2 - Self-test	51
9.9.2.3 Commissioning Stage 3 - Zoning Smoke Sensors	52
9.9.2.4 Commissioning Stage 4 – Flow test	53
9.9.2.5 Commissioning Stage 5 - Drainage	56
9.9.2.6 Commissioning Stage 6 – Sensor test	58
9.10 Programming the outputs	61

9.11 Enabling the Sounder monitoring	62
9.12 Clearing the commissioning memory	62
10 Hydraulic Calculations	62
Pipe Flow/Friction Factor Calculations I: (U.S. units)	62
11 Acceptance	63
11.1 General	63
12 Inspection, Testing and Maintenance	64
12.1 Inspection	64
12.1.1 Cleaning the strainer	64
12.2.1 Smoke Sensor Sensitivity Test	65
12.2.2 Smoke sensor activation test	66
12.2.3 Smoke sensor test mode	66
12.2.4 Testing the sounder output	67
12.2.5 Testing the Relays	67
12.3 Maintenance	67
Spray head weekly test	67
Cleaning the Smoke Sensors	68
Replace the consumables	68
12.3.1 Recommissioning after an activation	68
13 Troubleshooting	70
13.1 Error ID	70
14 Appendix	80
Table of Figures	80
15 Plumis part numbers	81
16 FCC Declaration	81
17 DIOM Version History	82

1. Administration

1.1 Scope

This DIOM is written to cover the design, installation, and maintenance of Automist, designed for the protection of one- and two-family dwellings, manufactured homes, and townhouses, as analogous to what NFPA 13D does for domestic sprinkler systems 13D sprinklers.

Automist is not designed for the protection of high-hazard applications such as hotels, offices, and industrial areas. It is also not designed for the protection of multi-family residential systems.

Automist follows the concept that a domestic suppression system is designed to protect against a fire originating from a single ignition location.

The smoke sensors connected to the Automist system are independent of any smoke detectors or fire alarm systems that are required to be installed in the property. The provision of an Automist system being installed cannot be used as a substitute for a fire alarm system in a home as required by code or an AHJ.

1.2 Purpose

The purpose of this Design, Installation, Operation and Maintenance (DIOM) Manual is to provide documentation for the design and installation of an automatic fire suppression system that aids in the detection and control of a domestic fire, avoid a flash-over (total room involvement) and improve the chance for occupants to escape or be evacuated.

To avoid serious or fatal injury, or major property damage, read and follow all safety instructions in this manual and on the product.

The following SAFETY SYMBOLS in the manual or on the product warn of HAZARDS that can cause fatality, personal injury, or property damage as described below.



Warns of ELECTRICAL HAZARDS that can cause fatality, serious personal injury, or major property damage.



Warns of NON-ELECTRICAL HAZARDS that can cause personal injury or property damage.



Warns of common installation mistakes. This symbol may denote both ELECTRICAL HAZARDS and NON-ELECTRICAL HAZARDS.

1.3 Installer Certification, Indemnification, release and waiver

1. Automist Installer hereby confirms and acknowledges that they have familiarized themselves with the Design, Installation, Operation and Maintenance (DIOM) Manual (the “**DIOM**”), which is intended to serve only as an informational resource for the Automist system (as defined therein, the “**Automist System**”). Automist Installer understands that the issuance of the valid certificate of

competence from the manufacturer (referred to in Section 3.1 of DIOM) designates only that the participating Automist Installer has completed the required course of instruction on Automist installation. It is not a certification of their professional experience, qualifications or performance. Plumis, a UK limited liability company, located at Unit 4, Phoenix Trading Estate, Bilton Rd, Perivale, UB6 7DZ UNITED KINGDOM ("**Plumis**") does not in any way endorse, guarantee or certify the experience, performance or quality of services of the Automist Installer.

2. AUTOMIST INSTALLER HEREBY AGREES TO THE BELOW DISCLAIMERS OF PLUMIS:

1) PLUMIS HEREBY DISCLAIMS ANY AND ALL LIABILITY FOR DAMAGES OR LOSSES OF ANY KIND OR NATURE TO PERSON(S) OR PROPERTY, INCLUDING, BUT NOT LIMITED TO, DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, ATTORNEYS' FEES OR COSTS, ARISING OUT OF OR RELATED TO THE INSTALLATION AND MAINTENANCE OF THE AUTOMIST SYSTEM BY THE AUTOMIST INSTALLER AND ANY OTHER SERVICES RELATED THERETO, INCLUDING, BUT NOT LIMITED TO ANY ADDITIONAL WORK PERFORMED BY THE AUTOMIST INSTALLER.

2) PLUMIS DISCLAIMS ALL WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE RELATED TO DIOM. NO ADVICE OR INFORMATION OBTAINED BY AUTOMIST INSTALLER FROM PLUMIS, OR ITS PERSONNEL OR THROUGH THE PLUMIS WEBSITE SHALL CREATE ANY WARRANTY OF ANY KIND BY PLUMIS.

3. AUTOMIST INSTALLER HEREBY AGREES TO WAIVE ANY AND ALL CLAIMS AGAINST PLUMIS, ITS OFFICERS, DIRECTORS AND EMPLOYEES, AND HOLD THEM HARMLESS FOR ANY DAMAGES OR LOSSES OF ANY KIND TO PERSON OR PROPERTY, INCLUDING, BUT NOT LIMITED TO, DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES ARISING OUT OF OR RELATED TO INSTALLATION, OR MAINTENANCE OF THE AUTOMIST SYSTEM PROVIDED BY AUTOMIST INSTALLER OR ITS PERSONNEL, AND/OR ANY OTHER SERVICES RELATED THERETO.

4. Automist Installer warrants and represents to be in compliance with all applicable laws, regulations, and ordinances. Automist Installer has and shall maintain in effect all the licenses, permissions, authorizations, consents, and permits that it needs to carry out its obligations related to the installation and maintenance of the Automist System.

5. Automist Installer shall indemnify, defend, and hold harmless Plumis and its officers, directors, employees, agents, affiliates, successors, and permitted assigns (collectively, "**Indemnified Party**") against any and all losses, damages, liabilities, deficiencies, claims, actions, judgments, settlements, interest, awards, penalties, fines, costs, or expenses of whatever kind, including reasonable attorneys' fees, fees and the costs of enforcing any right to indemnification under this Automist Installer Certification, Indemnification, Release and Waiver (the "**Installer Certification**"), and the cost of pursuing any insurance providers, incurred by Indemnified Party (collectively, "Losses"), arising out of or resulting from any claim of a customer or any third-party, for the benefit of whom the installation or maintenance of the Automist System are performed, arising out of or occurring in connection with acts or omissions of Automist Installer or its employees, agents or permitted contractors in connection with the performance of the installation or maintenance of the Automist System, or any other services related thereto, or any non-compliance with DIOM.

6. All non-public, confidential, or proprietary information of Plumis (the "**Confidential Information**"), including, but not limited to, specifications, samples, patterns, designs, plans, drawings, documents, data, business operations, customer lists, pricing, discounts, or rebates disclosed or made available by Plumis to Automist Installer, whether disclosed orally or disclosed or

accessed in written, electronic, or other form or media, and whether or not marked, designated, or otherwise identified as "confidential," in connection with the DIOM shall be deemed confidential, solely for Automist Installer's use in performing the Automist installation or maintenance, or any other services related thereto, and may not be disclosed or copied unless authorized by Plumis in writing. Confidential Information does not include any information that: (a) is or becomes generally available to the public other than as a result of Automist Installer's breach of this Installer Certification; (b) is obtained by Automist Installer on a non-confidential basis from a third-party that was not legally or contractually restricted from disclosing such information; (c) Automist Installer establishes by documentary evidence, was in Automist Installer's possession prior to Plumis's disclosure hereunder; or (d) was or is independently developed by Automist Installer without using any Confidential Information. Upon Plumis's request, Automist Installer shall promptly return all documents and other materials received from Plumis. Plumis shall be entitled to injunctive relief for any violation of this Section.

7. For a period of 5 years after the date of the DIOM training, Automist Installer shall, at its own expense, maintain and carry insurance in full force and effect with financially sound and reputable insurers, that includes, but is not limited to, commercial general liability with limits no less than \$1,000,000 per occurrence and \$ 2,000,000 in the aggregate, including bodily injury and property damage and completed operations and advertising liability. Upon Plumis's request, Automist Installer shall provide Plumis with a certificate of insurance evidencing the insurance coverage specified herein. The certificate of insurance shall evidence that Plumis is included as an additional insured on a primary, non-contributory basis, on Automist Installer's required insurance policies. Automist Installer shall provide Plumis with thirty (30) days' advance written notice in the event of a cancellation or material change in Automist Installer's required insurance policies. Except where prohibited by law, Automist Installer shall require its insurer to waive all rights of subrogation against Plumis's insurers, Plumis or the Indemnified Parties.

8. Automist Installer confirms that they understand that after Automist installation, a customer shall receive an installation certificate (the "**Installation Certificate**") issued by the Authorized Installer, which must include the installed address, the date of installation and the serial number of the Automist. Obtaining such Installation Certificate is a condition for the customer to enforce rights arising from the Limited Warranty.

9. This Installer Certification, and all matters arising out of or relating thereto, whether sounding in contract, tort, or statute are governed by, and construed in accordance with, the laws of the state of California, without giving effect to the conflict of laws provisions thereof to the extent such principles or rules would require or permit the application of the laws of any jurisdiction other than those of the state of California. Automist Installer irrevocably and unconditionally agrees that any action, litigation, or proceeding of any kind whatsoever against the other party in any way arising from or relating to this Installer Certification, including all exhibits, schedules, attachments, and appendices attached to this Installer Certification, and all contemplated transactions, including contract, equity, tort, fraud, and statutory claims, in any forum other than the U.S. District Court for the Central District of California or, if such court does not have subject-matter jurisdiction, the courts of the state of California sitting in Los Angeles, and any appellate court thereof. Such courts shall have the exclusive jurisdiction, and a final judgment in any such action, litigation, or proceeding is conclusive and may be enforced in other jurisdictions by suit on the judgment or in any other manner provided by law.

1.4 Retroactivity

This DIOM manual is updated from time to time with best practices or to be in line with existing codes and standards. An installation should be designed to the latest version of this manual and maintained with respect to the version at the time of installation, as installed hardware may not be compatible with the latest design, installation and maintenance practices which are designed to the latest hardware. The manual version used for the design and installation should be documented as part of the installation's working plans for future reference at the time of maintenance.

1.5 Equivalency

Nothing in this manual is intended to limit the use of or installation of Automist in ways which allow it to perform at an equal or better level than its Listing, using more sensitive aspiration detection systems, for example. However, any change to the system installation or operation outside the scope of this manual is also outside of the scope of the system's Listing and needs to be agreed with the AHJ beforehand. Technical documentation must be provided to the AHJ to demonstrate equivalency.

1.6 Units

All units in this manual are expressed primarily in SI units (m, Mpa, kg) and Imperial units (ft, psi, lb and fortnights) in brackets (). The values of measure in this manual were originally defined using the SI system and the conversion table below:

Name of Unit	Unit Symbol	Conversion Factor
litre	L	1 US gal = 2.377 L
pascal	Pa	1 psi = 6894.757 Pa
bar	Bar	1 psi = 0.0689 bar
bar	bar	1 bar = 10 ⁵ Pa
Metre	m	1 m = 3.28 ft

2. Definitions

2.1 Definitions

Automist Installer is responsible for commissioning the installation and confirming that it has been completed in line with these guidelines at the end of the installation.

Automist Designer is responsible for creating the working plan for Automist.

Electronically Controlled Automatic Nozzle Nozzles that are normally closed and operated by electrical energy that is initiated and supplied by fire detection and control equipment (as per NFPA 750 definition 3.3.25.2).

Authority Having Jurisdiction (AHJ) An organization, office or individual responsible for enforcing the requirements of code or standard, or for approving equipment, or materials, an installation or a procedure. As per NFPA 750 3.2.2. All other terms follow the definitions found in NFPA 750, NFPA 70 and NFPA 72.

Automist Working Plans are scale drawings displaying each floor of the property and highlighting information that pertains to the design of the system. It shall be submitted for approval to the authority having jurisdiction before any equipment is installed or remodelled .

Automist system Automist AP09 & Automist AP12 incorporate at least 1X smoke sensor (EVCA-PY-PL) 1X spray head (SH12) 1X Controller (CT03) 1X pump (AP09 or AP12) associated cables and piping. Throughout this manual references to Automist or the system refers to a combination of these parts to make up the complete Automist system.

3. General Requirements

3.1 Qualifications

All procedures must be performed by personnel qualified by Plumis. The design, working plan, maintenance, and installation of the Automist system in accordance with this DIOM shall only be performed by people knowledgeable and trained in such systems and with a valid certificate of competence from the manufacturer.

4 Automist System

4.1 Introduction

The system has been fire tested in a laboratory with a maximum ceiling height of 2.43m (8 ft), therefore Automist should not be installed in homes where the ceiling height exceeds this limit according to its UL Certification.

Water mist fire suppression systems have demonstrated their value in assisting the protection of life and property for many years. A correctly designed, installed, and properly maintained Automist fire suppression system can detect, suppress, and control a fire at an early stage of development.

The automatic operation of the system rapidly reduces the rate of production of heat and smoke, allowing more time for the occupants to escape to safety or be rescued.

The controller continually monitors the thermopile sensors by reading the temperature while parked, ensuring that all heads are ready to operate. When triggered by a Plumis wired sensor, all the linked spray heads will begin scanning. They start measuring the temperatures within the room using an infrared thermopile sensor.

When detecting the fire to target with water mist, the infrared sensor on the spray head captures thermal images of the room using a 750-pixel sensor and processes the footage using embedded machine learning. The spray head targets a fire, even if the view is partially obstructed because the radiant heat from the smoke and its heating of surfaces is also visible by the thermal imaging sensor.




Figure 1: Interpretation of how the IR sensor views the fire

Once the temperature exceeds a threshold that head is deemed to have successfully located a fire. All heads which locate a fire during a scan are then compared to see which has the best view.

The selected spray head will lock onto the selected location, and activate the high-pressure pump, driving mains water through the unique nozzle unit, quickly directing a dense fog into the location of the fire. The high momentum vertical spray orientation with a horizontal trajectory is designed so fires can be saturated with a turbulent flow of mist, suppressing the fire.

While the water is being discharged the system monitors the heat signature of the fire. If it establishes the fire is traveling, it will pause the pump and relocate the angle of the spray head to target the optimum location.

Traditionally, for enclosed spaces, water mist has a different principle of firefighting to traditional sprinklers which suppress fires by wetting surfaces and directly cooling the flames with large water drops. Water mist uses fine droplets, which evaporate at the base of the fire, to extract heat and displace the oxygen fuel. This results in fire control, suppression, or extinguishment. Automist uses a combination of both processes. The spray heads are wall mounted (around light switch height) to avoid ineffective evaporation in the hot layer in the ceiling and the upward flow of hot combustion products. Automist leverages the natural turbulence the fire creates and seeks to ensure water mist is entrained in the fire plume by targeting mist, at high pressure, directly at the base of the fire, while at the same time wetting the adjacent surfaces to impede the fire propagation.

The provision of Automist does not negate the need for other fire precautions or practical measures, which can include structural fire resistance, escape routes, smoke or fire sensors and safe housekeeping practices. Even with the installation of Automist, normal actions on the discovery of a fire need to be taken, such as immediate evacuation and the calling of the fire and rescue service.

Automist maintenance is not complex but is essential. Owners and occupiers must pay particular attention to the details within, such as the avoidance of obstructions to the water mist nozzle.

Some properties may require more than one Automist system to be installed in order to provide adequate suppression coverage. Where more than one system is installed in the property, the designer should avoid having spray heads in the same room connected to different Automist controllers. Where this cannot be avoided, the water supply to all Automist pumps must be sufficient for the provision for both pumps to be activated at the same time.

Where more than one Automist system is installed in the same property the systems cannot be interconnected. Each Automist pump, controller, spray heads and detection devices are independent from each other.

4.2 System Diagram

1. Smoke sensor (EVCA-PY-PL)
2. Spray head (SH12)
3. Pump (AP09)
4. Controller (CT03)
5. High-pressure pipe ¼" BSPP connection
6. 2 Core Sensor cable
7. 5 Core Data cable
8. Pump to controller cables (power and solenoid)




Figure 2: System Diagram

4.3 Technical limitations

Automist has been performance tested within the following operational boundaries:

- Maximum number of spray heads: 10
- Maximum number of smoke sensors in the system: 10
- Maximum number of smoke sensors in a series chain: 2
- Maximum number of scanning spray heads at the same time: 6
- Maximum number of spray heads per zone: 3
- The same sensor can belong to a maximum of 2 zones
- Maximum sensor cable length 90 m (295.27 ft)
- Maximum data cable length: 80 m (262.47 ft)
- Maximum high-pressure water pipe length: 60 m (196.85 ft)
- Maximum high-pressure water pipe length from the pump to the furthest spray head: 30 m (98.42 ft)
- Maximum sounder cable length is 90 m (295.27 ft)
- Installed where the room temperature is above 4 °C (39.2 F) and below 44°C (11.2 F)




Figure 3: Understanding the maximum hose lengths




Figure 4: Technical Limitations Summary

4.4 Spray Head



Figure 5: Spray head (SH12)

Spray head Software Version	v3.4_AH-0-e339155
Weight	1.4 kg
Size (main body)	133 mm (5.23 inch) (height) x 50 mm (1.96 inch) (depth) x 128 mm (5.03 inch) (width)
Size (back box)	119 mm (4.68 inch) (height) x 60 mm (2.36 inch) (depth) x 103 (4.05 inch) mm (width)
Operating Pressure	76 – 100 bar (1102 – 1450 Psi)
Flow rate	9 litres (2.37 gal) per minute
Spray Pattern	90° vertical blade
K Factor (Nominal)	1.04 lpm/V (bar) 0.072 gpm/V(psi)
Minimum nozzle waterway	1 mm
Input Voltage	24 VDC (reversed voltage protected)
Input Current	Max 0.5 A
Mounting	Indoor wall-mounted
Temperature & Humidity	Indoor, dry

4.5 Pump




Figure 6: Pump isometric view (AP09)




Figure 7: Pump side view (AP09)

Automist Pump Specification

AP09 230V 50Hz



The Automist pump comes in two variants AP09 and AP12. Ensure you have the correct pump to work with the electrical voltage supply in your country. Using the incorrect pump could result in electrical fires, electric shock and the system not performing as designed.

Weight	23 kg
Size	250 mm (9.84 inch) (height) x 300 mm (11.81 inch) (depth) x 400 mm (15.74 inch) (width)
Output Pressure	76 – 100 bar (1102 – 1450 Psi)
Flow rate	9 litres per minute (2.37 Gallons) per minute
Inlet Pressure (Dynamic)	1 – 3 bar (14.5 – 43.51 Psi)
Rated Motor Speed	2800 rpm
Input Voltage Pump	230V AC/50Hz
Input Current Pump	Max 13.5 amp
Input Power Pump	Max 3 Kw
Input Voltage Solenoid	24 VDC
Type of Solenoid	Normally closed (NC)
Temperature & Humidity	Indoor, dry

AP12 240V 60Hz

Below is the specification for an AP12 Automist pump utilising an incoming electrical supply of 240V 60Hz

Weight	23 kg
Size	250 mm (9.84 inch) (height) x 300 mm (11.81 inch) (depth) x 400 mm (15.74 inch) (width)
Output Pressure	76 – 100 bar (1102 – 1450 Psi)
Flow rate	9 litres per minute (2.37 Gallons) per minute
Inlet Pressure (Dynamic)	1 – 3 bar (14.5 – 43.51 Psi)
Rated Motor Speed	3400 rpm
Input Voltage Pump	240V AC/60Hz
Input Current Pump	Max 11.4 amp
Input Power Pump	Max 2.4 KW
Input Voltage Solenoid	24 VDC
Type of Solenoid	Normally closed (NC)
Temperature & Humidity	Indoor, dry

4.6 Controller




Figure 8: Automist Controller (CT03)

Automist Controller Specification

Input Supply	Single phase
Input Voltage	230V AC 50 Hz
	240V AC 60 Hz
Input Current Standby mode	Up to 0.5 A
Input Current Scanning mode	Up to 0.5 A
Input Current Pumping mode	13.7 A with 230V AC 50Hz pump (AP09)
	11.6 A with 240V AC 60HZ pump (AP12)
Input Current Controller Inrush	60 A peak
Input Current Motor Starting	75 A peak <150ms
Input Current Locked Rotor	52 A <30 s (motor protected by thermal fuse)
Overload Protection	Protection is provided by incoming power feed 20A MCB, no breakers inside the control unit. MCB is current limiting type with limitation class 2.
Safety Classification	Class I device, Earth must be fitted!
Overvoltage Category	Overvoltage Category II (transient protection via MOVs and GDTs to Earth/Ground)

Software version number	v1.14_AP-0-e7ec33c
Dimensions	325 mm (12.79 inch) W x 310 mm (12.2 inch) H x 80 mm (3.14 inch) D
Weight	6.75 kg (including battery)
Mounting Location	Indoor, dry environment only
Mounting Position	Within 3 m (9.84 ft) of the pump and recommended 0.5 – 1.5 m (1.64 - 4.92 ft) above the floor level
Temperature & Humidity	Indoor, dry

Controller terminals

Name	Type	Description
Relay Contact 1	Output (volt-free)	Activates when a fault is detected including AC power loss 30 VDC 1Amp Max
Relay Contact 2	Output (volt-free)	Activates when the system is scanning. 30 VDC 1Amp Max
Relay Contact 3	Output (volt-free)	Activates when the system is spraying. 30 VDC 1Amp Max
Alarm 1-5	Input / Output	Connects the controller to the smoke sensors. A maximum of 2 smoke sensors can be connected in series to one alarm output. N.B. Connect the shield to the SHLD terminal. Do not terminate the shield at the sensor end of the cable. 24V DC max load is 100 mA per channel
RS485 Primary	Input / Output	Connect the data cable from the controller to the spray heads. Provides RS485 communication, 24 V power supply and earth connection to the heads. Max Load is 500mA (continuous) 1.2A (1 Hour)
RS485 Secondary	n/a	Not active / Do not use
Solenoid 1	Output	Connection to 24 V solenoid. Connect the solenoid cable from the pump red 24V + black 0V -
Solenoid 2	n/a	Not active / Do not use
AC Power In	Input	230V AC 50 Hz / 240V 60 Hz power supply input
Battery	Input / Output	Connection to 12 V battery. Connect the battery leads red 12+ and black 0V –
Pump Out	Output	Power output for the pump motor
Sounder Circuit	Output	24 VDC 220 mA maximum load. 4.7K, 1W (minimum), \pm 5% EOL resistor to be fitted
USB	USB	Plumis use only
Pressure sensor	n/a	Not active / Do not use

Do Not Connect to a Receptacle controlled by a switch




Figure 9: Controller Terminals (CT03)

4.7 Smoke Sensor

EVCA-PY-PL

The EVCA-PY-PL is a conventional photoelectric 2-wire smoke sensor only for use with the Plumis Automist Fire Suppression System. Only the base model number EVA-UB4 or EVA-UB4-6 should be installed. Operating voltage of 24 VDC. Quiescent current of 50 μ A @ 24 V and alarm current of 50mA at 24V.

NOTE: The EVA-UB4 is the compatible model mounting base for the EVCA-PY-PL smoke sensor.

The Model EVA-UB4-6 mounting base is intended for applications where a 6-inch square or octagonal electrical junction box is required.



Figure 10: Plumis EVCA-PY-PL sensor

No alternative model of smoke or heat sensor can be used with the Automist system

4.8 Pipes and Fittings

All piping and fittings should be supplied and installed in accordance with the piping/fittings manufacturer's instructions and should be suitable for use at the working pressures and flows to be experienced by Automist with the necessary factors of safety-

Stainless Steel Piping

- Material: Stainless Steel only
- Stainless steel pipes and fittings must conform to
 - US (NFPA 750): ASTM A269 or ASTM A 632 or ASTM A 778 or ASTM A 789/ A 789M
- Internal diameter: 8 mm (5/16")
- Working pressure of at least: 175 bar (2538 Psi)
- 1/4" BSPP Female thread with swivel nut with 60° cone mating surface
- Hangers and fittings shall be evenly spaced to support the pipework at maximum operating pressure.

Given the small discharge orifice for Automist due to its low flow, it is important not to use sealant tape on fittings downstream of the strainer as these could dislodge and block the nozzle.

- Maximum total length: 60 m (196.85 ft)
- NFPA 750 6.4.3.4 Joint compound shall be applied only to male threads

- Avoid coating the last two threads of the male fitting to avoid compound breaking free and potentially causing a blockage in the nozzle.

4.9 Data and Sensor Cables

Data cable specification

- Model: Alphawire 2466C Only to be used

2 X 1 pair. Pair 1 red-black. Pair 2 colour green-white

22 AWG.

6.9 twists/foot

- Maximum length: 80 m (262.46 ft)

Sensor Cable Specifications

- Cable type: FLP (fire-rated low power)
- 2 wires
- Maximum length between spray head and the furthest smoke sensor: 90 m (295.27 ft)
- Not within Plumis' scope of supply
- Voltage rating: 150V+
- Current rating: 1A minimum
- Wire size: 18 AWG (could be 16 AWG or 20 AWG)

Wire Terminations

Data cables must be terminated with a data bus termination resistor rated at 120 ohm, 1W (minimum), $\pm 5\%$ at the last spray head. These are factory fitted to the spray head.

Smoke sensor cables must be terminated with a 4K7 ohm, 1W (minimum), $\pm 5\%$ resistor across the last sensor. These are factory fitted to the smoke sensor bases.

Sounder cables must be terminated with a UL listed 4K7 ohm, 1W (minimum), $\pm 5\%$ resistor in the sounder, if this is not already incorporated into your chosen sounder.

Bootlace Ferrule Specifications: Multicomp E0508-WHITE, 0.5 mm² / 22 AWG, pin length 8mm, overall length 14 mm. must be used for connecting the data cable to the spray heads.

4.10 Battery for Controller

Battery specification

- The standby battery shall be UL Recognized (BAZR2) lead acid, rechargeable NP7 12VDC 7-amp hour rated.
- Low battery to fully charged time = 20 hours
- Standby time provided = 24 hours

4.11 System Strainer

The Automist pump has a strainer incorporated to help prevent contaminants from entering the system and potentially causing blockages.

This is a Y-type strainer with a port for inspection and flush-out.

5 Spray Head Position and Location

5.1 Design Criteria

The placement of Automist spray heads is governed by simple design criteria. A single Automist spray head has a maximum 6 m (19.69 ft) range in front and 4 m (13.12 ft) range on either side along the wall. The spray pattern acknowledges it is easier for Automist to address fires in front of the spray head as opposed to alongside it.




Figure 11: Automist spray pattern



IMPORTANT! Keep clear 1.5 m (4.92 ft) radius around the head (see below) of obstructions and fire loads (e.g. refrigerators, sofas, microwaves).




Figure 12: Top view of the keep clear zone




Figure 13: Obstructions are not allowed in the keep clear zone

Visibility extends radially from each mist head and ends wherever there is an obstruction. If an obstruction is fixed (e.g. a kitchen island with splashback, large fridge, bookshelf, or a built-in wardrobe) and equal or more than 0.9 m (2.95 ft) high, it must be regarded as blocking the line of sight from any spray head positioned within 3 m (9.84 ft) and reflected in the working plan. Obstructions higher than 0.9 m (2.95 ft) and wider than 0.3 m (0.98 ft) must be regarded as blocking the line of sight at any distance.

The keep clear zones extends floor to ceiling. In rooms other than kitchens that may have overhead cupboards, there should be no fire loads or obstructions placed above the spray head within the keep clear zone.




Figure 14: Automist obstruction

An obstruction can impact the ability of an active fire suppression system to suppress a fire and its objective to cap the fire growth (limit the production of heat and toxic gas). The obstruction risk for the Automist system differs from traditional ceiling-mounted systems. The following must be considered (but not limited to):

	Automist
Spray head	Wall mounted
Obstruction Plane	Vertical
Examples of obstruction to either detection or suppression	Large wall-mounted furniture (e.g. a fridge, a bookcase, wall cupboard, cabinet, or wardrobe) too close (horizontally) to the spray head.

This excludes a householder disabling the suppression system by fully obstructing the spray head or by creating de facto room partitions is akin to wilfully removing fire alarms, decorating/painting over concealed sprinkler heads, or removing sensors and are beyond the scope of this recommendation.

IMPORTANT! The Automist head must be located where the spray pattern will not be obstructed, and 1.5 m (4.92 ft) horizontal clearance provided 180 degrees around the spray head. Where the

sprayhead cannot be located away from an obstruction, an additional sprayhead shall be located to cover the other side of the obstruction.

The overall objective of a working plan is to ensure the coverage pattern covers all the square footage within the property as required in NFPA 750.

5.2 Position of Spray Heads

The spray head must be installed at a height between 1.2 m – 1.3 m (3.94 ft – 4.27 ft 3) from the finished floor level. The height is measured from the finished floor level to the nozzle.




Figure 15: Automist nozzle height

If mounting above a worktop the mounting height must still be between 1.2 m – 1.3 m (3.94 ft – 4.27 ft 3) however there must be a clearance of at least 100 mm (4 inch) from the bottom of the upper cupboard (so the spray pattern is not affected by the cupboard above), if positioning above a worktop a distance of 400 mm (15.75 inch) must be maintained to clear any potential worktop objects). If these distances cannot be maintained without positioning the spray head within the standard mounting height an alternative position in the kitchen must be used.




Figure 16: Automist spray pattern




Figure 17: Automist in a kitchen




Figure 18: Automist spray head above a worktop

The spray head must be positioned at least:

- 1.5 m (4.92 ft) away from any hob
- 1.5 m (4.92) away from any oven (if in direct line of sight)
- 3 m (9.84 ft) away from any log burners or small fireplaces
- 0.3 – 0.5 m (0.98– 1.64 ft) away from the window frame edge to allow space for curtains



Figure 19: Clearance either side of a window

- 0.55 m (1.8 ft) away from an internal corner, If the spray head is too close to a corner it can be obstructed by movable furniture on the adjacent wall.




Figure 20: Bookshelf blocking a spray head (left) in keep clear zone an internal corner (right)

- 0.9 m (2.95 ft) from the door hinge so the head is not located behind the door and is considerate of the direction of the swing.




Figure 21: 0.9m (2.95 ft) away from the door hinge

Locate the spray heads in positions considerate of the principals below (where 1 supersedes 2, and 2 supersedes 3):

1. **Select a position where the likelihood of placing something directly in front of the spray head is reduced.**

Although the spray head is engraved with KEEP CLEAR and DO NOT COVER, use the proximity to a feature in the room where people are less likely to put something against the wall (e.g. alongside a light switch, or above a radiator).




Figure 22: Spray head alongside light switch picture (left) diagram (right)

2. Select a position with a direct and unobstructed line of sight to the fire risks.

Ensure most of the potential fire risks are in front of the spray head (e.g. the kitchen hob and dish washer or washing machine under the work surface). Typically, the only large movable item of furniture in the kitchen is the fridge. If all worktops, the oven, and the hob are 45 degrees in front of the spray head, only obstructing the spray head directly will obscure the view of the main fire risks. This configuration reduces the potential impact of placing something alongside the spray head.




Figure 23: Example of a good spray head location with a good line of sight to the kitchen fire risks

In an open-plan living room, the staircase is often an ideal location opposite the likely fire sources, such as the wall-mounted TV, sofa, and fireplace.

3. Select a position where the impact of placing something alongside the spray head is reduced.

Each room has a main risk in terms of tall moveable furniture (e.g. The fridge in a kitchen, the TV entertainment cabinet, tall drawers in a living room, or a wardrobe in a bedroom). The risk of obstruction is increased the longer the wall is, so shorter walls are preferred. In a rectangular room, it is preferable to spray with the length of the room, as opposed to across the length of the room assuming this does not conflict with a primary or secondary objective. As you can see (below) an obstruction alongside the head, removes more coverage for the latter.




Figure 24: Spraying with the length of the room




Figure 25: Spraying across the length room



If there is a concern a spray head may be obstructed, it is advisable to add another spray head into the affected room to add redundancy.

5.3 Working Plan Drawing

Plumis provides an online working plan tool required to facilitate the positioning of spray heads. The Automist installation shall be designed to facilitate easy maintenance. Parts requiring service or access (e.g. the pump and controller) shall be installed in an accessible location. Automist designs shall only be created by designers who have completed the Automist design training course.




Figure 26: Annotated Working Plan

5.4 Location of Spray Heads

When the system is used to meet the Building Code, the locations of spray heads and therefore the coverage or protected area shall follow the requirements in NFPA 750. Section 10.3.2.8 details which type of room requires suppression and which are excluded (e.g. small bathrooms, closets, pantries, garages, attics, and rooms in a tiny house).

When the system is used as a fire safety upgrade for enhancing an otherwise code-compliant dwelling, for example, for asset protection or homeowner elective installation, the rooms which require suppression is defined by the AHJ (see definitions).

6 Smoke Sensor Position and Location

6.1 Design Criteria

Detectors shall be installed in accordance with NFPA 72 where there is a conflict with the following rules, the Plumis rules below must be followed.

6.2 Position of Smoke Sensors

- 1) Where smoke sensors are installed, no bedroom door shall be further than 3 m (9.84 ft) from the nearest smoke sensor.
- 2) Sensors within rooms shall be sited such that no point is further than 5.3 m (17.38 ft) from the nearest smoke sensor.
- 3) Sensors shall be mounted on ceilings and shall be located at least 300 mm (11.38 inch) horizontally from any wall, border of a zone or light fitting unless, in the case of light fittings.
- 4) Ceiling-mounted sensor bases must be fixed directly to the ceiling and not countersunk.
- 5) Sensors shall be sited on smooth flat horizontal ceilings.
- 6) Where beams create an obstacle to the flow of smoke across a ceiling the beam must be considered as a wall:
 - a. The sensor must not be located on the beam.
 - b. Sensors must be provided on both sides of the beam.
 - c. The sensor must not be located closer than 300 mm (11.38 inch) to the beam.
- 7) Sensors shall not be mounted adjacent to, or directly above, heaters or air-conditioning vents.
- 8) Sensors shall be mounted in positions that are reasonably accessible for maintenance.
- 9) Sensors shall be located close to the middle point of the longest diagonal line for a zone with only one sensor. If a zone has multiple sensors, they shall be located along the longest diagonal line and have equal spacing between them.
- 10) A maximum of 2 sensors can be on any one circuit.

6.3 Smoke Sensor Working Plan

The location of the smoke sensors must be marked on the main working plan. See 8.3 includes all the core components that make up the system.

6.4 Smoke Sensor Location

Smoke sensors shall be installed in all the rooms which have a spray head.

7 Water Supply

7.1 Flow, Pressure and Temperature Requirements

The Automist fire pump is a positive displacement pump designed to discharge a constant flow of 9 litres (2.37gallons) per minute because only one Automist spray head will ever discharge at a fire, as this is electronically controlled. The Assumed Maximum Area of Operation (AMAO) is always a single spray head and therefore the pump only needs to supply the flow and pressure for that one spray head.

Where more than 1 Automist system is installed in the same property, if one room is being protected by spray heads on different systems, the water supply to each pump must be capable of delivering 11 litres (2.9 gallons) per minute.



The minimum required water supply (allowing for tolerance) is **1 bar (14.5 Psi) and 11 litres (2.9gallons)** of flow per minute.

The maximum water supply pressure is **3 bar (43.5 Psi)** when the pump is flowing.

The pump will operate automatically once a fire location and risk has been determined by the controller and will stop operating after 30 minutes (default operation time) or if the stop button is pressed on the controller.

7.2 Water Quality

The water supply for a water mist system shall be taken from a source that is equivalent in quality to a potable (drinkable) source with respect to particulate and dissolved solids.

8 Electrical Power Supply

8.1 230/240V 50/60Hz primary power

All electrical supplies to the Automist pump and controller should be installed in accordance with the regulations and requirements specific to your local jurisdiction. It is a requirement to install Automist on a separate circuit to the protected room and its contents. The fire detection and alarm system may use this circuit, as all must remain powered in the event of a fire.

8.2 12V Standby Battery

In the event of an electrical supply failure, the standby battery will power the controller for 24 hours. Power is supplied to the controller's display, alarms and sounder only. It does not supply power to the pump. The controller will display the battery voltage and beep intermittently to notify the resident there is an AC power problem and the system is running from the battery.

When the battery is low before the power is drained, the spray heads will move from the flush position to the locked inward position to give the resident a visual indication that a fault is present.

IMPORTANT! The standby battery is not designed to supply power to the system during an activation.

9. Installation

9.1 Water Supply (stock cock and pressure gauge)

- Install a 3/4" water supply (connection) with a certified lock lever valve positioned so that the connection point will not be obstructed when the pump is installed. The cold-water supply must deliver the following dynamic flow and pressure:

11 litres (2.9 Gallons) per minute and maximum of 3 bar (43.5 Psi), minimum of 1 bar (14.5 Psi). If over 3 bar (43.5 Psi), then a PRV needs to be fitted and set at 3 bar (43.5 Psi)

To measure for adequate flow, the measurement must be taken at the supply valve to the pump. Use a flow cup measure such as the one illustrated below.



Figure 27: Flow cup

Place a bucket under the flow cup to catch the water, turn on the water supply at the valve and ensure a flow of at least 11 litres (2.9 Gallons) is measured. If when using this type of flow measure device, the required flow rate looks as though it is on the limit, use a digital flow metre to confirm an accurate flow rate measurement.

- Install a UL certified low-pressure gauge between the isolation valve and the supply pipe to the pump.



Figure 28: Low-pressure gauge

9.2 High-Pressure Pipes and Fittings (indoor install)

Pipework fittings and supports should meet the recommendations detailed in NFPA 750 sections 6.4.3 and 6.5 or in accordance with the pipe manufacturers recommendations, consideration must be given to ensure that:

- a) Pipework supports should be fixed directly to the structural elements or primary supports of the building.
- b) Pipework supports should not be used to support any other services.
- c) Pipework supports should prevent the pipe from being dislodged.
- d) Supports should be secured in accordance with the piping/fittings manufacturer's instructions.
- e) Supports should not be glued, welded, or soldered to the pipe or fittings.
- f) Where necessary, supports for pipework should be suitably lined to prevent corrosion and abrasion.
- g) The maximum support spacing should be in accordance with the piping/fittings manufacturer's installation instructions.'

The water inlet assembly and pump, which is water-filled, should be in an area of the property where exposure to temperatures below 4 °C can be avoided. If this cannot be ensured, the location of this water-filled pipework should be protected against freezing. The high-pressure pipes do not need to be protected against freezing as they are kept dry until pump discharge.



IMPORTANT REMINDER! Before installation ensure the high-pressure pipes are in line with Plumis guidelines. The maximum total length of the high-pressure pipe is 60 m. The maximum allowable distance between the pump and the furthest spray head is 30m. High-pressure pipes must conform to NFPA 750.

High-pressure pipes can be connected in a star or a daisy chain configuration. See section 4.8 for the high-pressure pipe and fittings specification. Any plumbing joint or fittings must be made of stainless steel, e.g., t-connectors and elbows, and must be housed in an accessible area so they can be checked for leaks during the commissioning procedure.

IMPORTANT! Pipes must be closed with caps to prevent contaminants from entering the water path until the second fix.

IMPORTANT! So that fire separating is effective, every joint, or imperfection of fit, or opening to allow services to pass through the element which has fire-resisting function, should be adequately protected by sealing or fire stopping so that the fire resistance of the element is not impaired.

9.3 Data Cables

The spray heads must be connected in a daisy chain configuration; therefore, data cables must be **labelled IN and OUT** during the first fix so they can be correctly installed when connecting the spray heads during the second fix. It is recommended that the data cable(s), where possible, is loosely bound to the high-pressure pipe.

Data cables must be installed within the fabric of the building or be protected by a 30-minute rated fire barrier.

Data cables cannot be installed in a star configuration.

9.4 Smoke Sensor Wiring

Smoke sensors are connected to the alarm terminals on the controller.

Each alarm channel can have a maximum of 2 smoke sensors connected in series.

The shield wire is only connected at the controller end. Care should be taken to ensure the shield wire is not left exposed in the sensor base, which may cause a short circuit to any of the terminals in the smoke sensor base.

A 4K7 resistor is installed in the last sensor as shown below. Remove the factory installed resistor from the base if it is the first of two detectors in series as shown in the diagram below.




Figure 29: wiring connection when 2 smoke sensors are connected in series




Figure 30: Wiring connection when 1 smoke sensor is connected to the alarm channel.



IMPORTANT: The installer should consult with the designer with regard to the wiring configuration of the smoke sensors. If 2 smoke sensors are wired in series but will be programmed into different zones at the commissioning stage, both zones will be activated if either sensor is triggered. See section 9.8 for more details on zoning.

9.5 Spray Head Installation

The spray head must be installed on the wall at a height of **1.25m (4.10 ft) +/- 50 mm (1.96 inch)** measured from the finished floor level to the nozzle.

The Automist spray head can be mounted to the Automist backbox (AC21). The back box dimensions for the Automist spray head are 103 mm (4.05 inch) wide x 119 mm (4.68 inch) high and 60 mm (2.36 inch) deep.

Alternatively, the spray can be fixed to the wall using the 4 fixing holes in each corner of the spray head.

If the spray head is mounted in a drywall without a backbox, the whole required to house the spray head should be 86 mm (3.4 inch) wide by 119 mm (4.68 inch) length.

The spray heads are configured in a daisy chain configuration; therefore, **data cables must be labelled IN and OUT** during the first fix so they can be correctly wired during the second fix. It is recommended that the data cable(s) where possible, is loosely bound to the high-pressure pipe. Strip each core of the data cable to expose 10 mm of the wire and crimp a bootlace ferrule to each core of the data cable.

0.5 mm² / 22AWG, pin length 8 mm, overall length 14 mm.

Ensure your crimping tool is designed to crimp the required size ferrule, do not use pliers to crimp the ferrules to the cable as this can cause bad connections.



Figure 31: Electrical wire connectors ferrules


After inserting the red, black, green, and white wires as indicated on the terminals, turn the screw clockwise until tight. Use a torque screwdriver on the following setting: minimum 0.22 Nm, maximum 0.25 Nm. Test the connection by gently pulling on the wire to confirm it is not loose.

IMPORTANT! The alarm terminals on the back of the spray head are not used and should be left empty.

IMPORTANT! A 120-ohm data bus termination resistor must be wired across the green and white-out terminals of the last spray head. Remove any factory installed resistors from the spray heads terminals if it is not the last spray head in the chain.

The stainless-steel pipe connects to the spray head inlet with a ¼ inch BSPP Female thread with swivel nut with 60° cone mating surface. Hand tighten the pipe to the spray head and then apply 15 Nm of torque using a torque wrench.

Do not over-tighten the connection.

*Figure 32: Electrical connections on the spray heads with ferrules*

9.6 Controller Installation

The controller should be mounted securely to the wall with 4 fixings, the installer should consider the type / material of the wall the controller is being mounted on and that the controller weighs 6.75KG including the battery when choosing which fixings to use.

The controller should be mounted at a height where the homeowner can read the display and have easy access to the stop button.

The controller should be mounted within 3m (9.84 ft) of the pump.



Ensure the 230/240V electrical supply is isolated before connecting to the controller.

Use the glands provided to feed the cables into the controller. It is not necessary to use bootlace ferrules when connecting the wires to the controller's terminals.

Connect the data cable from the spray head to the primary RS485 terminals and the smoke sensor cables to the alarm terminals.

Pull the black plastic cover behind the display PCB to the left to access the AC mains supply terminals.

Connect the Live and Neutral from the electrical supply to the inlet supply terminals at the top of the PCB.

Connect the 230/240V AC supply cable to the pump to the outlet terminals at the bottom of the PCB.




Figure 33: Black plastic PCB high voltage cover tucked closed (left) or open (right)

Tuck the black plastic cover behind the display PCB.

Connect the earth cables from the 230/240V inlet supply (right photo above) and 230/240V pump outlet supply to the earth block on the controller (left photo above).

Connect the smoke sensor cables to the alarm terminals

Connect the sounder cable to terminals marked sounder

Connect the solenoid cable from the pump to the terminals marked solnd next to the batter terminals.

Connect the relay cables as required to the relay terminals.

Install the ferrite 742 722 22 supplied with the controller around the AC power cable, the ferrite should be installed immediately where the cable enters the controller as pictured below. be careful not to pinch the wire when closing the ferrite. If you need to open the ferrite to adjust or remove the cable, use the provided prong tool 74271 to unlock the ferrite.

The ferrite must be installed to conform with FCC regulations.



Figure 34: Ferrite installed to AC power cable

9.6.1 Connecting the Backup Battery

When installing or replacing the battery connect the red battery lead to the positive terminal and the black lead to the negative terminal.

The battery should be orientated as shown below to ensure the battery leads are kept away from any of the other cables in the controller.

When connecting the battery for the first time, See section 9.9 before powering on the system.



Figure 35: Controller Battery

Securely attach the earth wire ring terminal to the lid and secure the lid to the controller with the screws provided.



IMPORTANT: The earth connector to the lid must be connected, failure to do so could result in electric shock causing death or serious injury.

9.7 Pump Installation

The Automist pump should be:

- located such that it is unlikely to be affected by a fire.
- located where the temperature can be maintained above 4 °C (39.2 F) and below 44°C (11.2 F);
- protected against the effects of fire; and
- suitably protected against flooding

To mitigate overheating when running for long periods, the pump must be installed in locations with a clearance of 100 mm from any obstruction.

The pump is supplied with a prewired cable connected to the (internal) solenoid valve. This cable connects to the solenoid 24 VDC + and – terminals on the controller.

Connect the water inlet supply to the pump using a ¼" NPT fitting.

Connect the pipe to a brass or stainless steel 1/4" BSP Parallel Male x M22 x 1.5 Metric Female adapter to the pump's outlet port.



Figure 36: 1/4" BSP Parallel Male x M22 x 1.5 Metric Female adapter

NOTE: For ease of installation

connect the adapter to the high pressure pipe before connecting the adapter to the pump.

When connecting the adapter to the pump, hold the brass pump outlet connector with a wrench whilst tightening the adapter with a second wrench. This will prevent the outlet pipe in the pump from twisting when connecting the adapter.

Remove the screw and remove the lid of the pump connection point as indicated in the picture below.




Figure 37: How to open the pump connection point

After opening the lid from the casing, insert the bung from the CM09 commissioning kit to prevent anything falling into the pumps internal mechanism whilst wiring the pump.




Figure 38: Pump bung



The AC power cable between the controller and the pump must be rated for 230V 20 amp as a minimum specification.

The AC power cable between the controller and the pump for a 240V 60Hz pump must be rated as 240V 15amp as a minimum specification.

Feed the AC Power cable from the controller through the gland on the pump housing and hand tighten the gland to secure the cable.



The electrical supply from the internal workings of the pump to the pump's connection points are:

Red = Live
Black = Neutral
Green & White = Earth



Figure 39: Electrical supply connections

Feed the AC Power cable from the controller through the gland on the pump housing and hand-tighten the gland.

Crimp an insulated ring terminal connector M5 stud size to the Live, Neutral and Earth wire of the supply cable.

Connect the 230/240V AC Power supply to the pump's AC Power terminal as pictured below. The terminal prewired with the red wire is Live, the terminal prewired with the black wire is Neutral and the terminal with the prewired green cable is Earth.

For example, in the UK, the brown wire terminal is Live, the black wire terminal is Neutral, and the green/yellow wire terminal is Earth as illustrated below.

In the USA on a 240V 60Hz pump Line 1 would connect to the red terminal and Line 2 would be connected to the Black terminal. The earth wire must be connected to the green and white terminal




Figure 40: Automist Controller CT03

Once all pump wiring connections have been made, ensure the earth terminal is attached to the lid and hook the lid cover back into position. Secure the lid by tightening the lid fixing screw.



IMPORTANT: The earth connector to the lid must be connected, failure to do so could result in electric shock causing death or serious injury.

9.8 Zone Configuration

The Automist system can have up to 10 zones configured to the system. Each room would generally be classed as 1 zone; however, zones could be created from adjoining rooms or sections of a large room which requires more than 3 heads.




Figure 41: Yellow zone (above) contains 3 wall mounted spray heads and 2 ceiling mounted smoke sensors

Smoke sensors and spray heads are paired together to create a zone. If any sensor in a zone activates the paired spray head(s) will scan the room to look for fire.

The systems zones should be defined in the **Working Plan** and configured by the **Installer**.

Based on 4.3 Technical limitations:

- The same smoke sensor can belong to a maximum of 2 zones.
- Maximum number of Spray Heads per Zone: 3.
- Maximum number of smoke sensors connected in series chain: 2.
- The same spray head can belong to up to 5 zones.

For example, Zone X has 3 heads, Zone Y – 2 heads, Zone Z – 2 heads. Zone X and Y were triggered first, so 5 heads are scanning. Then Zone Z was triggered, but only one of the two heads was added to the scan, because of 6 scanning heads limit. The head that was added from the Zone Z is the one that was poked first during the Commission Address mode.




Figure 42: Zone Diagram

9.9 Powering up the system

Connect the battery, see section 7.6.1. Connect the red lead to the positive terminal and the black lead to the negative terminal of the battery.

Secure the lid to the controller and ensure the earth ring is connected to the controller.

Check the pump's wiring cover is securely fitted.

With the controller lid in place. Switch on the AC Power electrical supply to the system.

The controller will carry out a self-test diagnosis and display the Software version number.




Figure 43: Power up screen

If there are any faults on the system an error code will be displayed, the controller will beep, and the yellow trouble light will flash. See list of error code section for more information on errors and troubleshooting.

If no errors are present the system will be in an uncommissioned state. When the system is not commissioned the spray head LEDs are yellow and the controller is beeping.

The controller will display a prompt to set the time and date.

9.9.1 Setting the time and date

When the system is first powered up, or a commissioned system has been down powered for a long period of time, the controller will go straight to the time and date menu.

The time and date must be set before proceeding further.

If the controller does not go straight to the time and date menu proceed as described below.

To enter the menu mode, hold the LEFT button for 10 seconds. The controller will beep, and the display will show menu 1. Sounder.

Press the DOWN button and the display will change to 2. Time, to change the time press Right button the date will flash, use the UP or DOWN buttons to scroll through and select the correct year.

Press the Right button and scroll up or down to select the correct month.

Press the RIGHT button and use the UP and DOWN buttons to select the correct date of the month.

Press the RIGHT button and the display will show the time with the hours flashing, use the UP or Down button to select the hour. Note the system uses a 24-hour clock so 4 PM would be 16:00. Press the RIGHT button, the minutes will flash, use the UP or DOWN button to select the correct minutes. Press the RIGHT button to set the programmed time.

When in the menu mode if no buttons are pressed for 1 minute the controller will time out and return to idle mode.

If you need to go back a stage whilst setting the date or time press the LEFT button to go back one stage.

Pressing the LEFT button in the Menu mode will take the controller out of Menu mode.

NOTE: If the system has been down powered for period of time the system date and time may be lost. In this scenario when the controller is powered up, the system will go straight to the time menu. Set the date and time then return the system to idle mode. The display will show system healthy. If an error message occurs consult the error code section on this manual and repair the fault.

When the system is powered up for the first time after setting the time and date the system will be in uncommissioned mode.

9.9.2 Commissioning

Commissioning incorporates five stages:

1. **Addressing.** Where all the spray heads are bound to the system by linking their internal addresses to the RS 485 communication channel between the controller and spray heads.
2. **Spray head and data test.** The spray heads will start scanning and communications will be sent back down the RS 485 data bus to the controller.
3. **Smoke sensors and zoning.** Where the sensors and spray heads are placed into the different zones they have been specified to protect.
4. **Discharge (or flow).** Test each spray head to verify the correct pressure and water flow is being expelled from the nozzle. This replicates a response to a fire while allowing for the water to be collected.
5. **Drainage.** Where the water left in the piping is expelled through the spray heads to return the system to a dry, standby state.
6. **Sensor test** Tests the IR sensor to ensure the sensor can differentiate a temperature of at least 6 degrees C (42.8F

NOTE: After the system has been successfully commissioned and the face plate(s) have been fitted, the installer must complete the smoke sensor test mode to ensure the smoke sensors and spray heads have been paired correctly. See the smoke sensor test mode section (12.2.3) of this manual to complete this process.

9.9.2.1 Commissioning Stage 1 - Addressing

The yellow trouble light will flash on the controller, and the system will beep every 8 seconds, the display will show **Automist Uncommissioned** and the **date (hh:mm)** and **time (YYYY-MM-DD)**.




Figure 44: Uncommissioned Controller

Press and hold the LEFT and RIGHT buttons together for 10 seconds to enter the commissioning mode.

The display will show **Commission 1/6** indicating the system is in stage 1, followed by **Total heads 0** and – **Poke heads**.



Figure 45: Commissioning Stage 1

Poke each head by briefly and firmly pressing the side of the pivot head.



Figure 46: Gently press the outside surface of the spray head with your finger to address it

The spray head's LED will change from flashing yellow to green and the controller will beep to confirm the spray head has been registered to the system.

The display will show **Total Heads 1**.

Repeat the process for all the spray heads connected to the system and check the controller shows the correct number of spray heads registered into the system. If not check all the spray heads are green, if any are flashing yellow, "poke" the head to add it to the system.

When all the spray heads have been programmed press the RIGHT button on the controller.

9.9.2.2 Commissioning Stage 2 - Self-test

When entering commissioning stage 2 the controller will check, and where necessary update the software in the spray head. Depending on the number of spray heads connected and if the software requires updating, this can take between 3 seconds and 4 minutes to complete. A **progress counter from 0-100%** will show how much of the process is complete. During this time the spray head being checked will flash purple and the completed spray heads LED will be lit green.

Following the software check the system will then start to test the spray heads

The display will show **Testing Heads** with a **progress counter from 0-100%**. The spray heads will start to scan the room during the self-test. When the test is 100% complete the spray heads will return to the flush position with a green light.

The display will then show, **Testing heads: passed.**




Figure 47: Commissioning Stage 2

On the spray heads that pass the test the LED will light green. On the spray heads that fail the test the LED will light red. This can happen because of either the IR sensor or servo failure. If it does, enter Commissioning Stage 1 - address, unpair the head, and replace with a new one.

If the progress does not reach 100%, The spray head(s) that have bad RS485 connection will not indicate either green or red.

If the self-test fails, check all the spray heads in and out cables are wired the correct way round.

Check the colour of the wires connected to the correct terminal on the spray head and in the controller.

Press the RIGHT button to proceed to the next stage.

9.9.2.3 Commissioning Stage 3 - Zoning Smoke Sensors

Read section 9.8 of this manual explaining how the system is zoned before programming the system.

The display will then show **Commissioning 3/6** to show you have moved to stage 3 and **Total Zones 0** (where the first Zone ID created is 0).

The spray head's LED will change from green to yellow.

Activate the smoke sensor(s) that you want to allocate to Zone 0, the spray head's LED will turn red. The display will change to show **Zone ID : 0** and **Heads : 0**.

Poke the spray head(s) that you want to assign to Zone 0, and the LED will flash green, the number of green flashes indicates the number of spray heads programmed to that zone. These spray heads will scan if the smoke sensor(s) you just assigned activates.




Figure 48: Commissioning stage 3

If you assign a spray head to the smoke sensor in error, poke the spray head again to unpair the spray head with the smoke sensor, the spray head will turn red to indicate it has been unpaired. When the smoke sensor(s) have been paired with the spray head(s) check the number of heads shown on the display is the correct number of heads assigned to that zone.

Press the RIGHT button to save the allocation, the display will show, **Total Zones 1** and **Trigger Zone**.

To program the next zone, repeat the process of activating the smoke sensor(s) and head(s) that you want to program to the 2nd zone.

The display will count the number of total zones as each new zone is created.

When all zones have been programmed press the RIGHT button to go to the next stage, the display will show **clearing zones please wait** and then move to stage 4/6.

If you need to delete a zone during stage 3

1. Trigger **all** the smoke sensors that are in the zone.
2. Make the sure display shows **Zone ID: x**, and x is the Zone ID that is about to be deleted.
3. Poke all the heads that have green LED indication. If successful, the head LED will turn red.
4. Press RIGHT on the user interface to finish. Now the display shows **Total Zones: n-1**.

9.9.2.4 Commissioning Stage 4 – Flow test

The display will show **Commission and flow test 4/6** to show you are in stage 4. The display will show the number of heads tested compared to the number of heads programmed into the system.

The spray head's LED will glow red and lock pending head selection. Poke the first spray head the nozzle will point to a 90 degree angle.



Figure 49: Gently poke the spray head

The nozzle will then rest at a 90-degree position and the LED will turn solid yellow waiting for the flow test to begin.

Connect the commissioning hose (CM06) to the nozzle and place the other end of the hose in a bucket.




Figure 50: Gently poke the spray head to trigger the pump to run

Gently push the head 45 degrees to initiate the flow test. The head will begin to flash yellow to indicate water is about to flow, during this period the head may be pushed again, or the STOP button can be pressed on the controller to cancel the discharge test.

Once the pump is activated, the head will light blue, and the red discharge light will be illuminated on the controller. At this point, the pump can only be stopped by pressing the STOP button on the controller.

The pump will run for 1 minute, during the last 30 seconds record the pressure reading from the pressure gauge attached to the pump.

The pressure reading must be approx. 90 bar (1305.33 PSI).




Figure 51: Pump pressure gauge



IMPORTANT! The pump features a cut-out which will disable it if the pressure becomes excessive, so it is critically important not to leave an installed system with an out-of-spec pressure. By leaving an installed system with pressures outside the specified range, you could be liable for deaths or injuries. If the achieved output pressure is outside the specified range, refer to the commissioning troubleshooting guide and contact Plumis if the issue cannot be resolved.

IMPORTANT! Check and record that there are no leaks, use a flashlight to look into the cavity wall to ensure there is no leak from the spray head. Check there are no signs of leaks at the pump or along the high-pressure pipes, especially where there are any joints.

IMPORTANT! The commissioning tool must be removed after the discharge test and the water has stopped flowing into the bucket, otherwise, the spray head cannot return to its parked position.

IMPORTANT! Wipe the spray heads IR sensor dry with a clean dry cloth or tissue, to ensure that there is no water on the IR sensor.

When the commissioning hose has been removed and the sensor dried, poke the spray head. If the flow test has been successful, the head will return to the locked position (inward-looking) and the LED will be green.




Figure 52: Remove the commissioning hose and gently poke to close the spray head

Repeat the process for every spray head. When all the spray heads have been tested the controller's display will show the number of spray heads tested compared to the number of spray heads programmed in the system. The **NEXT** option will be displayed, you cannot proceed to the next stage until all the spray heads have been flow tested.




Figure 53: Commissioning stage 4

Remember to record the pressure readings of each spray head tested.

Press the RIGHT button on the controller to go to the next stage.

8.9.2.5 Commissioning Stage 5 - Drainage

The display on the controller will read **Commission 5/6 Drain pipes**. The spray head(s) will flash multi-coloured and return to the locked position to indicate you are in stage 5.



Figure 54: Commissioning stage 5

Connect an air compressor with a Schrader type female connector to the pump's inlet port.




Figure 55: Pump inlet port for air



IMPORTANT! The high-pressure pipe must be cleared of water by an air compressor pump with a maximum pressure of 8 bar (116 Psi). Start with the head that is highest and furthest from the pump and work your way back to the pump decreasing in height whilst ensuring you open every head in the system in turn.

NOTE: The spray heads when released from the locked position will expel some low-pressure water from the nozzle, be prepared to catch the water in a bucket or paper towel as soon as the spray head is poked.

Poke the first spray head to be drained to release it from the locked position.

Attach the commissioning hose to the nozzle and put the other end of the hose in a bucket to collect the expelled water.

When the air compressor is switched on some air and water will be expelled from the system causing the end of the hose to thrash about in the bucket, secure the end of the hose in the bucket or enlist a 2nd person to hold the end of the hose steady in the bucket.

Run the compressor until no more water is being collected in the bucket and only air is being expelled from the nozzle. The time required to expel the water will vary depending on the pipe routing and pipe lengths.

When the spray head is only expelling air, turn the compressor off and remove the commissioning hose from the spray head.

Poke the head to return it to the locked position, repeat this process and drain the other spray heads one by one.



IMPORTANT! Leaving water in high-pressure pipes following the commissioning/servicing process can lead to dripping nozzles, particularly if any part of the piping passes above the nozzles. To prevent this, the water must be expelled after commissioning.

When all the spray heads have been drained, remove the compressor from the pump inlet air port. The controller will display **NEXT** in the bottom right of the screen, press the RIGHT button to move to stage 6

9.9.2.6 Commissioning Stage 6 – Sensor test

The display will show Sensor test followed by the number of sensors to be tested. The spray heads LED will turn red.

Poke one of the spray heads, the spray head will point at a 90 degree angle and the LED will turn yellow.

Use a dry cloth or tissue to ensure any droplets are dried and removed from the thermal sensor.

Poke the head again and hold the palm of your hand in front of the sensor to generate at least 6 degree C (42.8F). of temperature difference comparing to the ambient room temperature.

When temperature difference is detected, it will flash green and return to the locked position and the LED will turn green. Repeat this process for each spray head, when all sensors have been checked the controller will display **FINISH** and the total number of tested heads will be displayed.




Figure 56: Sensor test

Press RIGHT on the controller to finish commissioning.

If the sensor test fails, the spray head will remain at a 90 degree angle. Clean the sensor with a soft tissue and poke the spray head again to carry out the test again.

If the sensor cannot be cleaned and continues to fail the test press the LEFT button to go back to Stage 1 and poke the head to decommission it from the system, replace the spray head and repeat the commissioning process to commission the new spray head to the system.

NOTE: The other spray heads will remain commissioned but during the drain pipes stage all nozzles should be drained after flow testing the replacement spray head

The controller will now display **Automist system healthy** and the **time** and **date** with the green power on LED illuminated. The spray heads will leave the locked position and return to the flush position.




Figure 57: Controller Automist System Healthy

Attach and fasten the front plate to the intermediate plate and align, ensuring parallelism to floor and wall.




Figure 58: Front plate attached on the spray head

Ensure there is good clearance around the rotating head and the front plate. It is recommended to perform a final sensor test mode to ensure the spray heads have the freedom to rotate. This is incorporated with the smoke sensor test mode. (see section 12.2.3).

After commissioning or recommissioning the system, you must test the smoke sensors, see section 12.2.3 to confirm correct operation and zoning.

9.10 Programming the outputs

The controllers' relays will default to operate as per table below

Relay	Configuration	On	Off
1	0 (default)	System is healthy and protecting from fire.	Possible reasons: System is not commissioned. Error in the system. No mains power supply.
	1	Error in the system.	System is healthy and protecting from fire.
	2	Power is on.	No mains power supply.
2	0 (default)	System is in scanning mode: smoke sensor activated.	System is not scanning for fire.
	1	Error in the system.	System is healthy and protecting from fire.
	2	Possible reasons: 1. System is in scanning mode: smoke sensor activated. 2. Fire is being suppressed: fire found, system is in mode pump and pump is running.	System is not scanning for fire and pump is not running.
3	0 (default)	Fire is being suppressed: fire found, Pump is activating.	System is not in Pump mode or stop button was pressed during the suppression.

Relay 3 is reserved for activating when the pump is running. If you want to reallocate the function of relay 1 and 2.

NOTE: Ensure the system is not in commissioning mode.

Hold the LEFT button for 10 seconds, the system will display **Sounder**, press the DOWN button twice and the display will show **Relays**.

Press the RIGHT button and the display will show **Relays config** and **Relay 1**.

Press the UP or DOWN buttons to navigate between relay 1 2 or 3.

Press the RIGHT button to **SELECT** the relay's function to be changed.

The display will show **Configure** and the **relay number** you are configuring the curser will flash on the relay configuration option number.

Press the UP or DOWN button to select either 0, 1 or 2 as described in the table above press the RIGHT button to **SET** the desired relay configuration.

The display will show **SAVING** and return to the relay config screen.

Keep pressing the LEFT button to go **BACK** to return the system to **System Healthy** idle mode.

NOTE: when in the Menu mode, if a button is not pressed for 1 minute the system will time out and revert back to idle mode, any changes not saved will need to be reprogramed by following the steps above.

9.11 Enabling the Sounder monitoring

By default, the sounder output is not monitored. If a sounder is installed the sounder monitoring must be enabled so the controller can monitor the EOL resistor in the sounder. To turn sounder monitoring on.

From the system healthy screen, hold LEFT for 10 seconds.

The display will show **Sounder**.

Press RIGHT to enter the sounder menu, the display will show **Enable**.

Press RIGHT the display will show **Sounder: off**.

Press DOWN the display will show **Sounder: on**.

Press RIGHT to **SET** the sounder to **on**. The display will show **Saving** and return to the **Enable** screen.

Press LEFT to go **back**, this will exit the menus and return the system to the system healthy screen.

9.12 Clearing the commissioning memory

Power cycle (switch the AC Power off and on) the system before attempting to recommission if the system has been powered for more than 1 hour.

IMPORTANT! Once the commissioning is cleared (default) , the system will need to be fully commissioned including the flow test before the system can be returned to operational mode.

To clear the commissioning memory, hold the RIGHT and LEFT buttons for 10 seconds to enter commissioning stage 1.

Hold the stop button for 10 seconds, the memory will be erased, and the system will beep and return to stage 1.

NOTE: Clearing the commissioning memory does not erase the controller event log.

10 Hydraulic Calculations

Automist is a pre-engineered system as per NFPA 3.3.13.7. All components connected to the water supply are designed to be installed according to pretested limitations. It has a maximum total pipe length of 60 m (196.85 ft). All fire tests were performed with the worst-case scenario; 60m total pipe lengths with an inner diameter of 8 mm (5/16").

Pipe Flow/Friction Factor Calculations I: (U.S. units)

1. Calculation of Head Loss, h_L , and Frictional Pressure Drop, ΔP_f , for given flow rate, Q , pipe diam., D , pipe length, L , pipe roughness, ϵ , and fluid properties, ρ & μ .
Determine Friction Factor, f , assuming completely turbulent flow

$$f = [1.14 + 2 \log_{10}(D/\epsilon)]^{-2}$$

Pipe Diameter, $D_{in} = 0.315$ in, **Pipe ID = 8 mm**

Pipe Diameter, $D = 0.0263$ ft

Pipe Roughness, $\epsilon = 0.00015$ ft, **Commercial Steel**

Friction Factor, $f = 0.03159$

Pipe Length, $L = 98.43$ ft, **Max Length = 30 m**

Cross-Sect. Area, $A = 0.0005$ ft²

Pipe Flow Rate, $Q = 0.006$ cfs, **Max Flow rate = 9.4 l/min**

Ave. Velocity, $V = 10.2$ ft/sec

Fluid Density, $\rho = 1.94$ slugs/ft³, **Water**

Reynolds number, $Re = 25,595$

Fluid Viscosity, $\mu = 0.00002034$ lb-sec/ft², **70 F (room temperature)**

2. Check on whether the given flow is “completely turbulent flow”.
(Calculate f with the transition region equation and see if differs from the one calculated above.)

$$f = \{-2 * \log_{10}[(\epsilon/D)/3.7 + (2.51/(Re * (f^{1/2})))]\}^{-2}$$

Transition Region Friction Factor, f :

$f = 0.0348$

Repeat calc of f using the new value of f :

$f = 0.0347$

Repeat again if necessary:

$f = 0.0347$

3. Calculate h_L and ΔP_f , using the final value for f calculated in step 2:

$$h_L = f(L/D)(V^2/2g) \text{ and } \Delta P_f = \rho g h_L$$

Frictional Head Loss, $h_L = 211.40$ ft

Frictional Pressure Drop, $\Delta P_f = 13193$ psf

Frictional Pressure Drop, $\Delta P_f = 91.62$ psi or **6.32 bar**

11 Acceptance

11.1 General

The system must be commissioned or recommissioned in the following circumstances.

- Once all the components of the system have been installed and the system is powered.
- As part of a yearly maintenance cycle.

- If plumbing or construction work takes place, new smoke sensors are installed, or maintenance work occurs which could affect the system.
- After an activation following a fire.
- Commissioning must be performed by a trained Installer.

Press and hold the LEFT and RIGHT buttons for 10 seconds to enter commissioning mode. You can only enter commissioning mode within 60 minutes of the system powering on, this is to avoid unwanted uncommissioning.



The smoke sensor test must be carried out after commissioning and recommissioning to confirm the smoke sensors and spray heads have been zoned correctly.

12 Inspection, Testing and Maintenance

The maintenance requirement for Automist is once per year. the maintenance consists of a visual inspection, smoke sensor tests and recommissioning the spray heads.

Only Automist trained contractors should carry out maintenance on the Automist system.

12.1 Inspection

The controller should show **system healthy** on the display panel, if there are any error messages displayed, or the system is beeping consult the troubleshooting section of this manual.

Ensure there is 1.5 m (4.92 ft) clearance around the spray heads, if an obstruction has been placed in sight of the spray head the homeowner should be instructed in writing to remove the obstruction.

During the service, it is required to inspect the mesh through the inspection port on the pump and clean the mesh when contamination is found.

Inspect the smoke sensors to ensure they are clean and have not been painted or covered up.

Determine whether any modifications have been carried out and whether the working plan is still accurate.

If there has been a material alteration to the building or its use beyond the scope of NFPA 750 an assessment should be made as to whether the category of system is still appropriate. For example, has the property been altered to a multi family dwelling.

12.1.1 Cleaning the strainer


During the annual inspection the pumps strainer port should be inspected.



Before starting this process isolate the water supply to the pump.

The water in the pipework will drain from the inspection port, place a container under the inspection port to collect the water or hose to drain the water away.

The amount of water drained will depend on the length of pipe from the isolation valve to the pump inlet.



undo the cap on the pump strainer port with a 23mm wrench



Remove the mesh filter and remove any debris and wash the mesh in clean water If required.



Insert the mesh filter back into the inspection port, ensure the washer is in place and tighten the inspection cap with a torque wrench to 20 Nm

12.2.1 Smoke Sensor Sensitivity Test

During the annual service, a sensitivity test should be carried out on the EVCA-PY-PL smoke sensor(s).

It is recommended to use the Trutest™ smoke sensitivity tester manufactured by detector testers. See the manufacturer's instructions for how to carry out the sensitivity test.

- The Trutest™ device must be set for use with photoelectric detectors.
- It is recommended the test is carried out using the slow ramp feature.
- The EVCA-PY-PL is a low-profile device.

- The EVCA-PY-PL is a photoelectric device.
- The sensitivity of the EVCA-PY-PL sensor must be in the range of 3.56%/ft to 4.78%/ft. If the sensor fails the sensitivity test it must be cleaned and retested, if the sensor fails again, it must be replaced.

12.2.2 Smoke sensor activation test

During the smoke sensor test mode see section (12.2.3). the following procedure should be used to test the smoke sensors. Sensors offer maximum performance when tested and maintained in compliance with NFPA 72. The sensor may be tested in the following ways:

1. To test the optical sensor using HSI FIRE & SAFETY Aerosol canned smoke testers HO-25S or HO-30S. From a distance of 2 to 4 ft. (0.6 to 1.2 m) aim spray for 1 - 2 seconds at the vents on the side of the sensor. The sensor will activate within 1 to 10 seconds if the sensor is functioning properly.
2. If using Smokesabre™ aerosol gently pull the sabre so it is fully extended. Hold the can vertically close to the sensor. Spray the sensor in 1-second bursts every 10 seconds as necessary.
3. Check that the sensor gives an alarm condition within 15 seconds. Check the red LED indicator lights on the sensor. If the red LED fails to light, check the power to the sensor and the wiring in the sensor base.
4. After the sensor has given the alarm condition, the sensor is reset by the control unit. It may be necessary to allow a short time to elapse before resetting the sensors, to allow any residual smoke from the test to disperse.
5. Sensors that fail these tests should be cleaned as described under the Cleaning the Smoke Sensors Section (below) and retested. If the sensors still fail these tests they should be replaced.
6. Before proceeding to the next sensor, ensure that the sensor previously tested does not re-operate due to the presence of residual aerosol.

12.2.3 Smoke sensor test mode

Once the system is commissioned smoke sensor test mode allows you to test the sensors in the home without activating the Automist pump, by causing the paired heads to begin scanning. Sensor testing is a normal part of the system's maintenance:

- In the **System healthy** idle mode, press and hold the Right button for 10 seconds to enter the *Test Mode*.
- The display will show **Test Mode**.
- Test the smoke sensor(s) (as detailed in 12.2.2). All paired heads flash yellow then red and scan, non-paired heads flash yellow then red but remain closed. The orange activated LED will flash on the controller while the spray head is scanning.
- Test all smoke sensors in turn and ensure the correct head(s) perform the scan when the sensor(s) are tested.

- The smoke sensor test mode is deactivated by pressing the STOP button; this will be confirmed by the GREEN LED returning to constantly lit and the display showing **System healthy**.
In this mode after a 15-minute period of inactivity, the system will time out and return to idle mode, and the display will show **System healthy**.
- After the test is complete ensure, the LED is not lit on the smoke sensor and the spray head is not scanning before leaving the test mode.

NOTE If during the smoke sensor test mode, the incorrect spray heads are scanning, reconfigure the zones in stage 3 of the commissioning process to ensure the correct smoke sensor(s) are paired with the correct spray head(s).

12.2.4 Testing the sounder output

To test the Souder output, from the system healthy screen.

Hold LEFT for 10 seconds.

The display will show **1. Sounder**.

Press the RIGHT button, the display will show **1. Enable**.

Press the DOWN button, the display will change to **2. Test**.

Press the RIGHT button to select sounder test function. The display will show **Sounder test** and **sounder: off**.

Press the DOWN button to toggle the sounder from **off** to **on**.

Press the DOWN button again to toggle the sounder back to **off**.

Press LEFT to go back to go back to the previous menu press, LEFT again to return the controller to the system healthy screen.

12.2.5 Testing the Relays

To test any of the three outputs, from the system healthy screen.

Hold LEFT for 10 seconds.

The display will show **1. Sounder**

Scroll using the DOWN button until the display shows **Relays**.

Press the RIGHT button to select the relay menu.

The display will show **1. RELAY 1**. Use the DOWN button to scroll to the relay you want to test.

Press RIGHT to select the relay, the display will show **1. Configure**

Press DOWN the display will show **2. Test**.

Press RIGHT to enter the relay test mode.

The Display will show a flashing **NC** or **NO**,

use the UP or DOWN buttons to toggle the state of the relay.

After testing the relay press LEFT to go back to the test menu. Use the UP or DOWN button to select a different relay to test or press LEFT repeatedly to back out of the menu until the display shows **System Healthy**.

12.3 Maintenance

Spray head weekly test

Once the system has been commissioned, the spray head(s) will move approximately 5 degrees once per week. The week is counted from the day the system is commissioned. This test will take place at 15:00 every week. There is a small noise emitted as the motor moves and resets the spray head.

NOTE If the system is power cycled where the AC Power supply and battery are disconnected and reconnected, this test will occur every 7 days from the day the system is powered up.

This is normal and it is recommended customers are made aware that this test is carried out automatically, so the resident does not assume a fault with the system if they see the spray head(s) briefly moving.

Cleaning the Smoke Sensors

IMPORTANT! Sensors must be serviced at least annually.

It is recommended that the smoke sensor be removed from its mounting base for easy cleaning and that sensors be cleaned at least once a year.



Do not disassemble, repair, or modify the smoke sensors. It may cause a fire or electric shock.

1. Carefully remove the sensor head from its base.
2. Use a soft, lint-free cloth, moistened with alcohol for sticky deposits, to clean the plastic enclosure.
3. Using a soft bristle brush (e.g. an artist's paintbrush) carefully brush between the vanes in a linear motion away from the apertures on the plastic enclosure.
4. Ensure that no debris remains on or around the photo chamber once cleaning is complete.
5. Reinstall the sensor.
6. Test the sensor according to the section below, Testing the sensors.
7. Set the system back to normal operation mode.

Replace the consumables

- Replace the standby battery every 5 years.
- Replace the smoke sensors every 10 years.

12.3.1 Recommissioning after an activation

IMPORTANT! Even a small fire in close proximity to any components could cause damage to parts of the system. It is important to inspect the full system post an incident.

After an activation, the display will show **uncommissioned** and the Yellow LED flash on the controller.

The spray head that activated will be pointing at the angle of the fire, the other spray heads will be in the locked position looking inwards.

After the pump has activated all the spray heads and smoke sensors in the zone that activated should be visually inspected for damage, tested, and recommissioned. The infrared sensors of the spray heads in the zone that activated should be cleaned.

All smoke sensors should be inspected and tested in smoke sensor test mode. The smoke sensor(s) in the zone that activated must be replaced.

Enter commissioning mode.

At stage 4, recommission all the spray heads in the zone that activated and any that may have been affected by the fire.

At stage 5, expel the water from **all the spray heads** connected to the system.

13 Troubleshooting

13.1 Error ID

If the Automist controller detects a fault the yellow LED will flash, and the controller will beep. The display will show an error ID code. Use the table below to identify the description of the error code and the suggested corrective action to resolve the issue.

The controller can be silenced by pressing the stop button. If after 24 hours the fault is still present the controller will start beeping again. Only by addressing and repairing the fault can the system be permanently silenced and returned to standby mode.

ID	Name	Description	Diagnostics and fixing
0	NO_ERROR	No error.	N/A
1	ERR_HEAD_ERROR_MOTOR_HI_GH_CURRENT	Spray head servo motor overcurrent.	<ol style="list-style-type: none"> 1. Find which spray head is flashing 1x red pulse per cycle. 2. Investigate if something is preventing the nozzle from scanning. 3. If no obvious reason – replace the spray head.
2	ERR_HEAD_ERROR_READING_TEMPERATURE	The spray head is not able to read the temperature.	<ol style="list-style-type: none"> 1. Find which spray head is flashing 2x red pulse per cycle. 2. Replace the spray head. <p>The most likely reason for this failure is a damaged spray head (internal wiring).</p>
3	ERR_HEAD_ERROR_MOTOR_POSITION	This error ID is only used to represent error 79 (ERR_SERVO_FEEDBACK_OUT_OF_RANGE) as head LED blinks.	Check Error ID 85 (ERR_HEAD_FAILED_WIGGLE_TEST).
4	ERR_HEAD_ERROR_COMMS_LOST	No communication between the controller and the spray head. NOTE: This is the error detected by the head. When the controller detects the same error, it displays ID 14.	<ol style="list-style-type: none"> 1. Find which spray head is flashing 4x red pulse per cycle. 2. If the system has been commissioned, make sure the spray head with the error has been poked during commission address mode. If not – return to commissioning. 3. Check the RS485 wiring. 4. Replace the spray head. If other spray heads are also in the same error – replace the controller.
5	ERR_HEAD_ERROR_RESERVED_ID2	N/A	N/A

6	ERR_HEAD_ERROR_RESERVED_ID3	N/A	N/A
7	ERR_HEAD_ERROR_SMOKE_SENSOR_SHORT_CIRCUIT	The smoke sensor input on the spray head is shorted. NOTE: Smoke sensor input on the head should not be used!	<ol style="list-style-type: none"> 1. Find which spray head is flashing 7x red pulse per cycle. 2. Check the smoke sensor wiring. 3. If the smoke sensor connected to the spray head is okay – replace the spray head.
8	ERR_HEAD_ERROR_RESERVED_ID4	N/A	N/A
9	ERR_HEAD_ERROR_WATCHDOG_RESET	Spray head software is getting stuck.	<ol style="list-style-type: none"> 1. Find which spray head is flashing 9x red pulse per cycle. 2. Restart the system. 3. If the error happens again, replace the spray head.
10	ERR_HEAD_ERROR_READING_FLASH	Spray head configuration memory failed.	<ol style="list-style-type: none"> 1. Find which spray head is flashing 10x red pulse per cycle. 2. Replace the spray head.
11	ERR_HEAD_ERROR_WRITING_FLASH	N/A	<ol style="list-style-type: none"> 1. N/A
12	ERR_HEAD_ERROR_RESERVED_ID5	N/A	N/A
13	ERR_HEAD_ERROR_IN_MOTION	The spray head detects long continuous servo movement and cannot take an accurate temperature reading (causing blurred images).	<ol style="list-style-type: none"> 1. Find which spray head is flashing 13x red pulse per cycle. 2. Check if the nozzle still scans freely. If yes – find the reason (e.g., the controller is requesting it to move). 3. If there is no external reason stopping its movement the servo feedback might be broken. Replace the spray head.
14	ERR_COMMS_LOST_WITH_HEAD	Controller – spray head communication is lost. The same as ID = 4 but seen from the controller side.	<ol style="list-style-type: none"> 1. Check the RS485 bus wiring. 2. Find if any of the spray heads are flashing 14x red pulse per cycle. This will reduce the scope of diagnostics. 3. If the wiring is ok, replace the spray head. 4. If the error persists – replace the controller. <p>NOTE: If replacing the head that was commissioned, first go to Commissioning Stage 1 - Addressing and unpair it (if possible). Otherwise, the controller will give this error until the fault is rectified.</p>

15	ERR_CTLR_COMMANDS_FAILING	Certain commands of RS485 communication with the spray head is failing.	<ol style="list-style-type: none"> 1. Check the RS485 bus wiring (e.g. integrity of wiring and connections). 2. Replace the spray head. 3. If the error persists – replace the controller.
16	ERR_CTLR_PAIRER_SMOKE_SENSOR_NOT_BROADCASTING	N/A	N/A
17	ERR_SMOKE_SENSOR_OPEN_CIRCUIT	Commissioned smoke sensor end-of-line resistor is not detected.	<ol style="list-style-type: none"> 1. Check if every smoke sensor is secured on its base. 2. Check the smoke sensor's wiring. 3. If the wiring is correct, replace the spray heads one by one, so see that it has a wired connection to the smoke sensors. 4. If the error persists - replace the controller.
18	ERR_SMOKE_SENSOR_WIRELESS_BATTERY_LOW	N/A	N/A
19	ERR_SMOKE_SENSOR_WIRELESS_GENERAL_FAULT	N/A	N/A
20	ERR_SMOKE_SENSOR_DIRTY_SENSOR	N/A	N/A
21	ERR_SMOKE_SENSOR_TAMPER	N/A	N/A
22	ERR_READING_FLASH	Controller configuration memory is failed.	Replace the controller.
23	ERR_WRITING_FLASH	N/A	N/A
24	ERR_BUTTON_STUCK	The user interface button is pressed for more than 30 seconds.	<ol style="list-style-type: none"> 1. Make sure the buttons are not being held or stuck (e.g. because of some dirt). If possible – remove the cause of the stuck button. 2. Replace the controller.
25	ERR_DIRECT_SMOKE_SENSOR_SHORT_CIRCUIT	The smoke sensor input on the controller has been shorted.	<ol style="list-style-type: none"> 1. Check the wiring of the smoke sensors to the controller. 2. If no short circuits are present – replace the controller.
26	ERR_SM_COMMS_AR_LOST	Controller internal communication error.	<ol style="list-style-type: none"> 1. Disconnect the battery. 2. Power cycle the controller. 3. Reconnect the battery. 4. If error persists – replace the controller.
27	ERR_SM_COMMS_HV_LOST		
28	ERR_SM_COMMS_PM_LOST		
29	ERR_SM_COMMS_UI_LOST		

30	ERR_SM_COMMS_AR_COMMA NDS_FAILING		
31	ERR_SM_COMMS_HV_COMMA NDS_FAILING		
32	ERR_SM_COMMS_PM_COMMA NDS_FAILING		
33	ERR_SM_COMMS_UI_COMMA NDS_FAILING		
34	ERR_PUMP_TEST	The pump motor test failed.	<p>Possible cause:</p> <ol style="list-style-type: none"> Short circuit (motor + wiring resistance < 0.3 Ohms). Open circuit (motor + wiring resistance > 3 Ohms). Residual voltage (> 1V) detected on the motor and the test cannot be started. At least one motor wire is shorted to the ground. The resistance measurement circuit is faulty. <p>To resolve:</p> <ol style="list-style-type: none"> Check the wiring between the controller and pump and make sure the resistance is within limits. If the wiring is correct – replace the controller.
35	ERR_MAINS_MONITORING	The AC Power monitoring circuit is faulty.	Replace the controller.
36	ERR_HV_DCDC_FAIL	Controller internal failure.	Replace the controller.
37	ERR_SOLENOID_1_FAULT	Solenoid fault 1.	<p>Possible cause:</p> <ol style="list-style-type: none"> Open Circuit. Short Circuit. Short to ground or power supply. <p>To resolve:</p> <ol style="list-style-type: none"> Check the Solenoid 1 wiring. Replace the Solenoid 1. If the error persists - replace the controller.
38	ERR_SOLENOID_2_FAULT	Solenoid fault 2.	<p>Possible cause:</p> <ol style="list-style-type: none"> Open Circuit. Short Circuit.

			3. Short to ground or power supply. To resolve: <ol style="list-style-type: none"> 1. Check the Solenoid 2 wiring. 2. Replace the Solenoid 2. 3. If the error persists - replace the controller.
39	ERR_AR_RELAY_FAULT	The controller relay outputs driving circuit is faulty.	Replace the controller.
40	ERR_GROUND_FAULT_LIMIT_LOW	Ground is shorted to 0V.	<ol style="list-style-type: none"> 1. Check the wiring. 2. Find which node shorts ground to 0V and replace. 3. If the error persists - replace the controller.
41	ERR_GROUND_FAULT_LIMIT_HIGH	Ground is shorted to 24V.	<ol style="list-style-type: none"> 1. Check the wiring. 2. Find which node shorts ground to 24V and replace. 3. If the error persists - replace the controller.
42	ERR_COMM1_24V_FAULT_LIMIT_LOW	Controller RS485 bus 24V voltage is too low.	<ol style="list-style-type: none"> 1. Disconnect all the wires from the controller RS485 primary connector. 2. If this error goes away – connect node by node to find which node is causing the voltage to drop. 3. If the error persists – replace the controller.
43	ERR_COMM1_24V_FAULT_LIMIT_HIGH	Controller RS485 bus 24V voltage is too high.	<ol style="list-style-type: none"> 1. Disconnect all the wires from the controller RS485 primary connector. 2. If this error goes away – connect node by node to find which node is causing the error. 3. If the error persists – replace the controller.
44	ERR_COMM2_24V_FAULT_LIMIT_LOW	N/A	N/A
45	ERR_COMM2_24V_FAULT_LIMIT_HIGH	N/A	N/A
46	ERR_COMM1_24V_DRIVE_FAULT	Controller RS485 bus 24V circuit failure.	Possible reasons: <ol style="list-style-type: none"> 1. Undervoltage / Overvoltage. 2. Overcurrent. 3. Reverse current. 4. Overheat. Steps to resolve:

			<ol style="list-style-type: none"> 1. Disconnect all the wires from the controller RS485 primary connector. 2. If this error goes away – connect node by node to find which node is causing the error. 3. If the error persists – replace the controller.
47	ERR_COMM2_24V_DRIVE_FAULT	N/A	N/A
48	ERR_COMM1_OVERCURRENT_FAULT	Controller RS485 bus 24V overcurrent.	<p>1.25 A current limit is exceeded.</p> <p>Steps to resolve:</p> <ol style="list-style-type: none"> 1. Disconnect all the wires from the controller RS485 primary connector. 2. If this error goes away – connect node by node to find which node is causing the error. 3. If the error persists – replace the controller.
49	ERR_COMM2_OVERCURRENT_FAULT	N/A	N/A
50	ERR_COMM1_MID_LEVEL_FAULT_LIMIT_LOW	RS485 bus communication lines A or B are shorted to 0V.	<ol style="list-style-type: none"> 1. Check the wiring. 2. Disconnect node by node till the error goes away. 3. Replace the broken node (spray head). 4. If the error persists by disconnecting all the nodes – replace the controller.
51	ERR_COMM1_MID_LEVEL_FAULT_LIMIT_HIGH	RS485 bus communication lines A or B are shorted to 24V.	<ol style="list-style-type: none"> 1. Check the wiring. 2. Disconnect node by node till the error goes away. 3. Replace the broken node (spray head). 4. If the error persists by disconnecting all the nodes – replace the controller.
52	ERR_COMM2_MID_LEVEL_FAULT_LIMIT_LOW	N/A	N/A
53	ERR_COMM2_MID_LEVEL_FAULT_LIMIT_HIGH	N/A	N/A
54	ERR_PRES_5V_FAULT_LIMIT_LOW	N/A	N/A

55	ERR_PRES_5V_FAULT_LIMIT_HI GH	N/A	N/A
56	ERR_PRES_IN_FAULT_LIMIT_LO W	N/A	N/A
57	ERR_PRES_IN_FAULT_LIMIT_HI GH	N/A	N/A
58	ERR_SND_24V_FAULT_LIMIT_L OW	The sounder's driving voltage is too low.	<ol style="list-style-type: none"> 1. Disconnect sounder. 2. If the error goes away – replace the sounder. 3. If the error persists - replace the controller.
59	ERR_SND_24V_FAULT_LIMIT_HI GH	The sounder's driving voltage is too high.	<ol style="list-style-type: none"> 1. Disconnect sounder. 2. If the error goes away – replace the sounder. 3. If the error persists - replace the controller.
60	ERR_SND_END_OF_LINE_RESIST OR_FAULT	The sounder end-of-line resistor is not detected.	<ol style="list-style-type: none"> 1. Check the sounder wiring. 2. Make sure the end-of-line resistor is present. 3. Replace the sounder. 4. If the error persists – replace the controller.
61	ERR_SND_OVERCURRENT_FAUL T	The sounder's using too much current.	<p>Current has exceeded 200 mA.</p> <ol style="list-style-type: none"> 1. Check the wiring. 2. Replace the sounder. 3. If the error persists – replace the controller.
62	ERR_SND_DRIVE_FAULT	Controller sounder driving circuit failure.	<p>Possible reasons:</p> <ol style="list-style-type: none"> 1. Undervoltage / Overvoltage. 2. Overcurrent. 3. Reverse current. 4. Overheat. <p>Steps to resolve:</p> <ol style="list-style-type: none"> 1. Disconnect the sounder. 2. If this error goes away – replace the sounder / check the wiring. 3. If the error persists – replace the controller.
63	ERR_PUMP_DRIVE_FAULT	Controller pump driving circuit failure.	Replace the controller.

64	ERR_PM_BATTERY_VOLTAGE_LIMIT_LOW	The backup battery is disconnected or very low voltage.	The measured battery voltage is < 8V. 1. Make sure the battery is connected. 2. Make sure the battery voltage is > 8V. 3. If the error persists after connecting a good battery – replace the controller.
65	ERR_PM_BATTERY_UNDERVOLTAGE_LIMIT	The backup battery voltage is low.	The measured battery voltage is < 11V. 1. Wait for a few hours, the battery should charge automatically, and the error will disappear. 2. If the error doesn't go away – replace the battery. 3. If the error persists after replacing the battery – replace the controller.
66	ERR_PM_BATTERY_OVERVOLTAGE_LIMIT	The backup battery voltage is too high.	Measured battery voltage is > 14.5V. 1. Check the wiring. 2. Replace the battery. 3. If the error persists – replace the controller.
67	ERR_PM_CHARGER_FAULT	N/A	N/A
68	ERR_PM_5V_FAULT	N/A	N/A
69	ERR_PM_3V3_FAULT	Controller internal error.	Replace the controller.
70	ERR_PM_BATTERY_TEST_FAULT	The backup battery is faulty.	The measured battery internal resistance + wiring resistance is > 0.2 ohms. 1. Check the connections. 2. Replace the battery. 3. If the error persists – replace the controller.
71	ERR_PM_24V_FAULT_LIMIT_LOW	Controller internal error.	Replace the controller.
72	ERR_PM_24V_FAULT_LIMIT_HIGH	Controller internal error.	Replace the controller.
73	ERR_PM_REF_VOLTGE_LIMIT_LOW	Controller internal error.	Replace the controller.
74	ERR_PM_REF_VOLTGE_LIMIT_HIGH	Controller internal error.	Replace the controller.
75	ERR_OS_FAULT	The controller failed to initialize. Some functions might not work.	1. Disconnect the battery. 2. Power cycle the controller.

			<ol style="list-style-type: none"> 3. Reconnect the battery. 4. If the error persists – replace the controller.
76	ERR_SW_UPDATE_FAULT	The controller failed to initialize. Some functions might not work.	<ol style="list-style-type: none"> 1. Disconnect the battery. 2. Power cycle the controller. 3. Reconnect the battery. 4. If the error persists – replace the controller.
77	ERR_RTC_HARDWARE	Controller internal error.	Replace the controller.
78	ERR_PCB_TEMP_SENSOR_HARDWARE	N/A	N/A
79	ERR_SERVO_FEEDBACK_OUT_OF_RANGE	The spray head's main body position is not in the requested position.	<p>Possible cause:</p> <ol style="list-style-type: none"> 1. The main body is stuck. 2. The Servo motor is faulty. <p>To resolve:</p> <ol style="list-style-type: none"> 1. Find which head is producing this fault. 2. If no obvious reason (e.g., some external body is not allowing the head to move) - replace the head.
80	ERR_SETTINGS_DATA_LOST	The controller configuration is not valid / lost.	<p>Possible cause:</p> <ol style="list-style-type: none"> 1. The very first power on. 2. EMC noise during configuration saving. 3. Controller internal fault. <p>To resolve:</p> <ol style="list-style-type: none"> 1. Disconnect the battery. 2. Power cycle. 3. Reconnect the battery. 4. If the error persists – replace the controller.
81	ERR_HEAD_TOO_MANY_BAD_PIXELS	The spray head temperature sensor is faulty.	<p>The spray head has more than 7 bad pixels.</p> <ol style="list-style-type: none"> 1. Find which spray head is faulty. 2. Replace the spray head.
82	ERR_RTC_TIME_LOST	System time has been lost due to the discharged supercapacitor.	<ol style="list-style-type: none"> 1. Enter the time and the error will be cleared. 2. Make sure that the system has been powered up for at least an hour (to charge the supercapacitor).

			3. If fully powering off and powering on (with the battery disconnected) is causing this error to re-appear – replace the controller.
83	ERR_PM_TEMP_SENSOR_HARDWARE	The temperature sensor responsible for battery charging is not working, battery cannot be charged.	Replace the controller.
84	ERR_UI_LED_DRIVER_HARDWARE	User Interface LEDs and LCD backlight are not working.	Replace the controller.
85	ERR_HEAD_FAILED_WIGGLE_TEST	<p>During periodic head movement, one or more spray heads have reported at least one of the following errors:</p> <ul style="list-style-type: none"> • (1) ERR_HEAD_ERROR_MOTOR_HIGH_CURRENT • (2) ERR_HEAD_ERROR_READING_TEMPERATURE • (3 / 79) ERR_SERVO_FEEDBACK_OUT_OF_RANGE / ERR_HEAD_ERROR_MOTOR_POSITION <p>The spray head that has failed is blinking yellow. The number of blinks represents the error.</p>	<ol style="list-style-type: none"> 1. Check which spray heads are blinking red or yellow. 2. Count the number of blinks between long pauses. 3. Check the reference of actions for each of the errors. 4. Press the STOP button to clear the error.

14 Appendix

Table of Figures

Figure 1: Interpretation of how the IR sensor views the fire.....	9
Figure 2: System Diagram	11
Figure 3: Understanding the maximum hose lengths.....	12
Figure 4: Technical Limitations Summary	13
Figure 5: Spray head (SH12).....	14
Figure 6: Pump isometric view (AP09).....	16
Figure 7: Pump side view (AP09)	16
Figure 8: Automist Controller (CT03).....	18
Figure 9: Controller Terminals (CT03).....	20
Figure 10: Plumis EVCA-PY-PL sensor	21
Figure 11: Automist spray pattern	23
Figure 12: Top view of the keep clear zone	24
Figure 13: Obstructions are not allowed in the keep clear zone	24
Figure 14: Automist obstruction.....	25
Figure 15: Automist nozzle height.....	26
Figure 16: Automist spray pattern	27
Figure 17: Automist in a kitchen	27
Figure 18: Automist spray head above a worktop.....	28
Figure 19: Clearance either side of a window	28
Figure 20: Bookshelf blocking a spray head (left) in keep clear zone an internal corner (right)	29
Figure 21: 0.9m (2.95 ft) away from the door hinge	29
Figure 22: Spray head alongside light switch picture (left) diagram (right)	29
Figure 23: Example of a good spray head location with a good line of sight to the kitchen fire risks.....	30
Figure 24: Spraying with the length of the room	31
Figure 25: Spraying across the length room.....	31
Figure 26: Annotated Working Plan.....	32
Figure 27: Flow cup	35
Figure 28: Low-pressure gauge	36
Figure 29: wiring connection when 2 smoke sensors are connected in series.....	37
Figure 30: Wiring connection when 1 smoke sensor is connected to the alarm channel.	38
Figure 31: Electrical wire connectors ferrules	39
Figure 32: Electrical connections on the spray heads with ferrules	39
Figure 33: Black plastic PCB high voltage cover tucked closed (left) or open (right)	41
Figure 34: Ferrite installed to AC power cable.....	41
Figure 35: Controller Battery	42
Figure 36: 1/4" BSP Parallel Male x M22 x 1.5 Metric Female adapter	43
Figure 37: How to open the pump connection point	44
Figure 38: Pump bung.....	44
Figure 39: Electrical supply connections	45
Figure 40: Automist Controller CT03	46

Figure 41: Yellow zone (above) contains 3 wall mounted spray heads and 2 ceiling mounted smoke sensors	47
Figure 42: Zone Diagram.....	47
Figure 43: Power up screen	48
Figure 44: Uncommissioned Controller	50
Figure 45: Commissioning Stage 1	50
Figure 46: Gently press the outside surface of the spray head with your finger to address it	51
Figure 47: Commissioning Stage 2	52
Figure 48: Commissioning stage 3	53
Figure 49: Gently poke the spray head	54
Figure 50: Gently poke the spray head to trigger the pump to run	54
Figure 51: Pump pressure gauge	55
Figure 52: Remove the commissioning hose and gently poke to close the spray head	56
Figure 53: Commissioning stage 4	56
Figure 54: Commissioning stage 5	57
Figure 55: Pump inlet port for air	57
Figure 56: Sensor test	59
Figure 57: Controller Automist System Healthy	60
Figure 58: Front plate attached on the spray head	60

15 Plumis part numbers

Plumis manufacture and supply the core components of the Automist system, other components can be sourced locally from various suppliers such as flow and pressure gauges, cable ferrules and data cable.

Plumis parts and part numbers are listed below.

Part number	Description	Plumis SKU order number
SH12	Automist spray head	SH12
AC21	Back box for SH12 spray head	AC21
AP12	Automist pump 240V 60Hz version	AP12
AP09	Automist pump 230V 50 Hz version	AP09
CT03	Automist controller	CT03
CM09	Automist commissioning kit	CM09
EVCA-PY-PL	Smoke sensor	DT03
EVA-UB4	Smoke sensor base 4" diameter	DT04
UB4- UB4-6	Smoke sensor base 6" diameter	DT05

16 FCC Declaration

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

17 DIOM Version History

This version 2.0 supersedes version 1.1 effective September 2025

- I. The wiring diagrams for the smoke sensor base, fig 29 & 30 have been updated to ensure the correct fault monitoring is detected by the controller when a smoke sensor is moved from the base.
- II. Added imperial measurement to back box on page 35.
- III. Added section 12.1.1 for instruction on how to inspect the pump strainer port.
- IV. Added section 1.3 Installer Certification, Indemnification, release and waiver.
- V. Added section 12.2.5 Testing the relays.
- VI. Added to section 8.2 feature of spray heads locking on AC fail and low battery.
- VII. Updated software version number to specification in section 4.6.
- VIII. Added spray head software version number to specification in section 4.4.